



Operator's Manual



Hydraulic Post Driver

Model HD-8 & HD-8-H

Safety

Operation

Maintenance

Repair

Troubleshooting

Parts

Contents

Safety	2	Service Parts	38
Safety Alert Symbols	3	Driver Assembly	38
Safety Icon Nomenclature	3	Manual Base Plate Assembly	40
Safety Warnings	4	Hydraulic Base Plate Assembly	42
General Safety	4	Three-Point Hitch Assembly	44
Hazard Avoidance	4	Hydraulic Hoses	44
Hydraulic Hoses	5	Safety Arm Assembly	44
Introduction	6	Replacement Decals	45
Product Information	6	Document Tube	45
Specifications	6	Hydraulic Control Valves	46
Assembly Procedure	7	Single Control Lever Valve	46
Recommended Tools	7	Expanded View of Safety Lever Assembly	46
Unpacking	7	Triple Control Lever Valve	46
Assembly	8	Drive Cylinder Assembly	47
Main Carriage Channel	8	Tilt Cylinder Assembly	48
Stabilizer Legs	9	Limited Warranty	49
Base Plate	10	Warranty Card	50
Hydraulic Valve	12		
Safety Stop Adjustment	15		
Rubber Debris Guard	16		
Safety Arm	16		
Document Storage Tube	19		
Post Driver Operation	20		
Operational Safety Tips	20		
Operating Instructions	20		
Mounting	20		
Preparing to Drive a Post	21		
Driving a Post	22		
Placing Post Driver into Storage	25		
Troubleshooting	26		
Storage	27		
Service Procedures	27		
Three-Point Hitch/Post Driver Assembly	28		
Main Carriage Channel Disassembly	28		
Drive Cylinder Seal Replacement	30		
Main Carriage Channel Assembly	32		
Forward and Side Tilt Cylinder Maintenance	34		
Cylinder Disassembly	34		
Cylinder Assembly	35		
Three-Point Hitch/Post Driver Assembly	37		

Safety

Most work related accidents are caused by failure to observe basic safety rules or precautions. An accident can often be avoided by recognizing potentially hazardous situations before an accident occurs. As you assemble and operate the Shaver Post Driver, you must be alert to potential hazards. You should also have the necessary training, skills, and tools to perform this assembly procedure.

Improper operation and maintenance of this implement could result in a dangerous situation that could cause injury or death.

Do not assemble, operate, or maintain the Shaver Post Driver until you read and understand the information contained in this manual.



Safety precautions and warnings are provided in this manual and on the product. If these hazard warnings are not heeded, bodily injury or death could occur to you or to other persons.

Shaver Manufacturing Company cannot anticipate every possible circumstance that might involve a potential hazard. The warnings in this supplement and on the product are, therefore, not all-inclusive. If a method of operation not specifically recommended by Shaver Manufacturing Company is used, you must satisfy yourself that it is safe for you and for others. You should also ensure that the implement will not be damaged or be made unsafe by the methods that you choose.

The information, specifications, and illustrations in this supplement are based on the information that was available at the time this material was written and can change at any time.

Safety Alert Symbols



The safety alert symbol means **Attention! Become Alert! Your Safety is Involved.**

Hazards are identified by the “Safety Alert Symbol” and are followed by the signal word “WARNING”.

WARNING

WARNING: Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.

Potential damage situations are identified by the signal words “*IMPORTANT NOTICE*”.

IMPORTANT NOTICE

Indicates that equipment or property damage can result if instructions are not followed.

Safety Icon Nomenclature



Read the manual



Eye protection



Foot protection



Hand protection



Hearing protection



Inspect equipment



Two person operation



Warning decal alert



Bending hazard (hydraulic hose)



Crushing hazard



Crushing hazard (hand)



Do not weld



Electrocution hazard



Explosion hazard



High-pressure fluid hazard



Impact hazard (hydraulic hose)



Pressurized fluid



Projectile hazard (body)



Protective guards



Safety alert symbol



Slipping hazard



Tripping hazard

Safety Warnings

General Safety

WARNING



To avoid personal injury or death, carefully read and understand all instructions before attempting to assemble and/or operate the Post Driver. Do not operate or work on equipment unless you read and understand the instructions and warnings in this and all other applicable manuals. Contact Shaver Manufacturing Co. if any of the instructions provided are unclear or not understood. Proper care is your responsibility. Always follow all State and Federal health and safety laws and/or local regulations.



To help prevent personal injury, protective equipment must be worn during Post Driver assembly, operation, and maintenance. Personal protective equipment should include, but not be limited to, safety glasses, hearing protection, protective gloves, and steel toe footwear.



Personal injury can result from slips or falls. DO NOT leave tools or parts laying around the work area, and clean up all spilled fluids immediately.

Hazard Avoidance

WARNING



Inspect this equipment before each use. Make sure all hardware is tight. Always replace worn or damaged parts before use.



To avoid personal injury or death, do not operate the Post Driver by yourself. Always have another person to control the machine or power source.

WARNING



Make sure all decals are securely attached to the Post Driver and are legible at all times. Always read and understand all decals before working on or operating the Post Driver.



Make sure all lock-pins and transport supports are secured in place before transporting or storing the Post Driver. While transporting, never ride on or permit others to ride on the Post Driver.



Improper operating procedures can create risk for the operator and bystanders. DO NOT use the Post Driver before making sure no one will be endangered.



To prevent personal injury or death, be aware of overhead electrical lines when operating the Post Driver. Electrocutation can occur even without direct contact with overhead power lines. Proceed cautiously around electrical lines and utility poles.



To prevent personal injury or death, always check for underground utilities such as electrical wires, gas lines, and water pipes before driving posts. Contact local utility companies for information on locating underground utilities.



To avoid serious injury or death, do not operate the Post Driver on steep slopes, as this can cause a roll over.



To avoid personal injury, always stand 45 degrees to the right of the post being driven while operating the Post Driver.

! WARNING



Potential pinch points. Keep hands clear of Post Driver while operating. Never place hand(s) on top of a post when inserting it into the Post Driver. Always close the safety arm before driving the post.



To avoid personal injury do not attempt to clean, adjust, or lubricate the Post Driver while it is in motion.



The rubber debris guard helps shield the operator from flying debris that may be generated during post driving. To avoid personal injury, make sure the rubber debris guard is securely attached to the Post Driver before driving posts.



To avoid personal injury or death, do not modify the Post Driver by welding, drilling, or grinding. Do not expose to extreme heat, such as from a torch.



The main carriage channel assembly is tall and heavy. To avoid tip over, resulting in serious injury or death, leave the overhead lifting device attached to the main carriage channel while assembling components.



To avoid serious injury or death, the safety arm must be installed after the Post Driver has been mounted on a machine, or the freestanding Post Driver has been secured to prevent tipping.

Hydraulic Hoses

! WARNING



Avoid damaging hydraulic hoses. Avoid sharp bends and kinks when routing hydraulic hoses. Using a bent or kinked hose will cause severe back-pressure. Sharp bends and kinks can internally damage the hose, leading to premature hose failure, resulting in personal injury.

! WARNING



Do not drop heavy objects on hoses. A sharp impact may cause internal damage to the hose. Applying pressure to a damaged hose may cause it to rupture, resulting in personal injury.



Mismatched couplings and hoses can cause the coupling to violently disconnect from the hose when placed under pressure; separating with sudden, extreme force which can result in property damage, personal injury, or death.

Replace a hose if any of the following conditions are present:

- End fittings that are damaged or leaking
- Outer coverings that are chafed or cut
- Wire shields that are exposed
- Outer coverings that are ballooning
- Flexible part of the hoses that are kinked
- End fittings that are displaced



Pressure can be trapped in a hydraulic system. Trapped pressure can cause sudden movement of an attachment. Use caution when disconnecting hydraulic lines or fittings. High-pressure oil that is released can cause a hose to move violently while spraying oil.



Escaping high pressure fluid can penetrate the skin, causing serious injury. Relieve pressure before unhooking hoses. Check/tighten all connections before activating hydraulics. Never use your hand to check for leaks.

Introduction

The Shaver Manufacturing Company would like to congratulate you on your purchase of the Shaver Hydraulic Post Driver. You have selected the best Post Driver in its class. The clean design and uncomplicated working principle have made Shaver the largest selling Post Driver in the country.

The Shaver Hydraulic Post Driver is a durable piece of equipment that, with regular maintenance, will provide many years of service.

This manual provides information regarding assembly, operation, and maintenance. It is important to read and become familiar with this manual before assembling or operating the Shaver Hydraulic Post Driver.

NOTE: For other valuable information on farm equipment operation and safety, refer to the following resources.

- **Farm Equipment Manufacturers Association (FEMA)**
<http://www.farmequip.org/home>
- **National Ag Safety Database**
<http://www.cdc.gov/nasd/>

Product Information

Record Shaver product information here. The model number and serial number are found on the metal tag attached to the drive ram.



Model Number _____

Serial Number _____

Date Purchased _____

Dealer Name _____

Specifications


HD-8 & HD-8-H Post Driver	
Approximate Height ¹	88 in (223.5 cm) minimum 133 in (337.8 cm) maximum
Approximate Width	30 in (76.2 cm)
Approximate Depth	28 in (71.1 cm)
Shipping Weight	385 lbs (174.6 kg) manual base 433 lbs (196.4 kg) hydraulic base
Effective Weight of Spring Powered Driving Ram	360 lbs (163.3 kg)
Impact (at full stroke)	30,000 lbs (13,607.8 kg)
Operating Distance ¹	53 - 126 in (134.6 - 320.0 cm)
Main Carriage Channel Tilt	
Front/Back	15°/15°
Side/Side	15°/15°
Guide Blocks	4 (2 per side)
Mounting	Tractor (rear or front), skid steer
Three-Point Hitch	Category I and II
Hydraulic Requirements	3 - 4 GPM at 1500 PSI (11.3 - 15.1 LPM at 10,342 kPa)
Post Size	
Maximum Width	7.125 in (18.1 cm)
Maximum Length	10 ft (3.0 m)

¹ With Main Carriage Channel resting on the ground.

Assembly Procedure

Recommended Tools

The tools needed to assemble the HD-8 and HD-8-H Post Driver are shown below. Additional specialized tools are required for maintenance and seal replacement.



HD-8 & HD-8-H Recommended Assembly Tools		
No.	Description	Qty
T1	1-1/8 Inch Box End Wrench	1
T2	1-1/16 Inch Box End Wrench	1
T3	3/4 Inch Box End Wrench	1
T4	9/16 Inch Box End Wrench	1
T5	1/2 Inch Drive Impact Gun	1
T6	1-1/16 Inch Impact Socket	1
T7	15/16 Inch Impact Socket	1
T8	Soft Mallet or Hammer	1
T9	1/2 Inch Drive Ratchet	1
T10	3/8 Inch Drive Ratchet	1
T11	9/16 Inch Deepwell Socket (3/8 inch drive)	1
T12	1/2 Inch Deepwell Socket (3/8 inch drive)	1
—	Heavy-Duty Snap Ring Pliers ¹ (not shown)	1
—	Soft Brass or Wood Drift ¹ (not shown)	1
—	Heavy-Duty Seal Pick ¹ (not shown)	1

¹ Required for cylinder seal replacement.

Unpacking

! WARNING



Due to the size and weight of the Post Driver, two people are required for the assembly procedures.

The Post Driver is shipped in several sections: the driving ram assembly, base plate assembly, short channel bracket, hose and valve carton, safety arm carton, and on model HD-8-H, the tilt cylinder carton.

! WARNING



Before starting the unpacking procedure, make sure the overhead lifting device or material handling device (forklift) has adequate lifting capacity. Follow all safety recommendations when unpacking the Post Driver. Some components are heavy and can cause serious injury or death if not adequately supported during removal and assembly.

For ease of assembly, unload the Post Driver components in the area where they will be assembled. Choose a large, hard surface area that can safely support the weight of the assembled implement and is accessible by the machine it will be mounted on.



Assembly

NOTE: Refer to the Service Parts section of this manual for a photo and description of all the parts.

The HD-8 main carriage channel has provisions for mounting carriage channel bracket in three positions.

- Six middle bolt openings - three-point hitch (most common position).
- Six upper bolt openings - tractor front mount.
- Six lower bolt openings - for driving 10 ft (3.05 m) tall posts only - three-point hitch or front tractor mount.

The HD-8 and HD-8-H are shipped with the carriage channel bolts installed in the middle mounting position.

IMPORTANT NOTICE


To prevent damage to the lift cylinder, if moving the carriage bracket mounting bolts to a different mounting location, it is necessary to disconnect the lift cylinder from the main carriage channel assembly. Do this procedure before raising (standing up) the main carriage channel. For instructions on disconnecting the lift cylinder, refer to the Service Information section in this manual.

The Post Driver assembly procedure consists of the following subsections:

1. Main Carriage Channel
2. Stabilizer Legs (optional)
3. Base Plate
4. Hydraulic Valve
5. Safety Stop Adjustment
6. Rubber Debris Guard
7. Safety Arm

Main Carriage Channel

1. With road lock pin (B8) installed in the lower hole of drive ram (A1), use a suitable overhead lifting device to raise (stand up) main carriage channel (B1).



(A1) Drive Ram. (B1) Main Carriage Channel.
(B8) Road Lock Pin.


! WARNING



The main carriage channel assembly is tall and heavy. To avoid tip over, resulting in serious injury or death, leave the overhead lifting device attached to the main carriage channel while assembling components.


2. Install the appropriate short channel bracket (D2) using bolts (D3), lock washers (D4), and nuts (D5) (four each). Tighten completely.

NOTE: Hydraulic short channel bracket (D2) shown. Manual short channel bracket (D1) installation is the same.



(D2) Short Channel Bracket. (D3) Bolt. (D4) Lock Washer. (D5) Nuts.

3. Remove road lock pin (B8) from lower hole in drive ram (A1). Use spring tension to help raise main carriage channel (B1) and insert road lock pin (B8) in upper hole (tool storage position) in drive ram (A1). Install Lynch pin (B9) in road lock pin.




(A1) Drive Ram. (B1) Main Carriage Channel. (B8) Road Lock Pin. (B9) Lynch Pin.

Stabilizer Legs


1. Place three-point hitch weldment (K1) upside down on the floor. Install stabilizer leg brackets (K2) over the cross tube, as shown. Tighten two leg bracket bolts (K3) to secure brackets to cross tube.

NOTE: Loosen stabilizer leg bracket lock bolts, and remove stabilizer legs from brackets before mounting brackets on cross tube.




(K1) Three-Point Hitch Weldment. (K2) Leg Brackets. (K3) Leg Bracket Bolt.

2. Install stabilizer legs (K7) in leg brackets (K2), as shown.



(K2) Leg Brackets. (K7) Stabilizer Legs.


- Set stabilizer leg (K7) height at 4" (10.2 cm) measured from three-point hitch weldment (K1) cross tube to stabilizer leg base plate, as shown. Tighten stabilizer leg lock bolts (K8) (not shown).



(K1) Three-Point Hitch Weldment. (K7) Stabilizer Leg.

NOTE: If the upper set of holes are used to mount channel bracket (D1 or D2), the height of the legs should be set to 14" (35.6 cm). If the lower set of holes are used, the stabilizer legs cannot be attached.

- Turn over the three-point hitch weldment (K1) and set it on stabilizer leg (K7) base plates, as shown.




(K1) Three-Point Hitch Weldment. (K7) Stabilizer Legs.

Base Plate


NOTE: Manual base plate (E2) shown. Installation of hydraulic base plate (F2) is the same.

- Remove the mounting hardware from manual base plate (E2). Save hardware for reuse.



(E2) Manual Base Plate.

- Install manual base plate (E2) on three-point hitch weldment (K1). Install hardware removed in Step 1. Center the base plate on the three-point hitch and tighten the hardware securely.



(E2) Manual Base Plate. (K1) Three-Point Hitch Weldment.


- Remove and save channel mounting pins (D6) (not shown) from base plate (E2). Get assistance to position the base plate in front of short channel bracket (D1).

NOTE: If necessary, use a suitable floor jack to support the three-point hitch weldment. Loosen stabilizer leg lock bolts (K8), and adjust stabilizer legs up or down to align base plate pivot pin holes with manual channel bracket mounts.




(D1) Short Channel Bracket. (E2) Base Plate.
(K8) Stabilizer Leg Lock Bolts.

- If necessary, adjust forward tilt crank (E11) and side tilt crank (E3) to align channel mounting pin holes. Install lower channel mounting pin (D6) first and then upper channel mounting pin (D6). Secure pins with Lynch pins (D7).



(D6) Channel Mounting Pin. (D7) Lynch Pin. (E3) Side Tilt Crank. (E11) Forward Tilt Crank.

NOTE: For hydraulic short channel bracket (D2) only: Make sure safety lever plate (F9) is installed at upper channel mounting pin (D6), as shown.



(D2) Short Channel Bracket (hydraulic).
(D6) Channel Mounting Pin. (F9) Safety Lever Plate.

- Completed assembly with manual tilt base plate (E2).



Completed Assembly.

Hydraulic Valve


The customer must supply suitable hydraulic quick disconnect fittings to attach pressure supply hose (G17) and return hose (G20) to the tractor or power supply hydraulic system.

IMPORTANT NOTICE

The hydraulic valve and cylinder(s) can be damaged by contamination (dirt and debris) from the oil in the tractor or power source. Ensure the oil is clean and properly filtered before connecting the Post Driver to a hydraulic power source. Failure to follow oil cleanliness standards voids the Shaver Post Driver warranty.

NOTE: The hydraulic control valve for hydraulic tilt base plate (F2) has additional hose connections. Installation information for the additional hoses is covered at the end of this section.

1. Lay out the hydraulic control valve and related components.




(G1) Single Lever Control Valve. (G2) Valve Mounting Bolts. (G3) Washers. (G4) Nuts. (G5) Control Valve Lever. (G6) Control Valve Lever Knob. (G10) Safety Lever Return Spring. (G11) Clevis Pin (short). (G12) Clevis Pin (long). (G13) Cotter Pin (3 qty) (not shown). (G16) Pipe Fitting - 1/2" NPT 90° Elbow. (G18) Fitting - 3/4" NPT to 3/8" NPT Reducer. (G19) Pipe Fitting - 3/8" NPT 90° Elbow. (G21) Pipe Fitting - 3/4" NPT 90° Elbow.

2. Install the hydraulic valve on the short channel bracket (D1, D2) using three 5/16-18 x 3" valve mounting bolts (G2), washers (G3), and nuts (G4). Do not overtighten hardware.

IMPORTANT NOTICE


All hydraulic system fittings must be installed with a paste-type thread sealant only. Do not use a tape-type sealer such as Teflon Tape, as this can contaminate the system and voids the valve warranty.

3. Assemble the hydraulic control valve.
Single lever control valve (G1) for manual base plate or triple lever control valve (H1) for hydraulic base plate.
 - a. Remove the plugs from the hydraulic control valve. Apply pipe thread sealant compound to threads and install hydraulic fittings (G16, G17, G18, G19, and G21). Refer to photographs for correct placement and orientation.



Manual Tilt Base Control Valve.



(G16) Pipe Fitting - 1/2" NPT 90° Elbow. (G18) Fitting - 3/4" NPT to 3/8" NPT Reducer. (G19) Pipe Fitting - 3/8" NPT 90° Elbow. (G21) Pipe Fitting - 3/4" NPT 90° Elbow.



Hydraulic Tilt Base Control Valve.


(G16) Pipe Fitting - 1/2 NPT 90° Elbow. (G18) Fitting - 3/4" NPT to 3/8" NPT Reducer. (G19) Pipe Fitting - 3/8" NPT 90° Elbow. (G21) Pipe Fitting - 3/4" NPT 90° Elbow. (H3) Adapter Fitting - 1/2 NPT Male to 1/2 NPT Female Swivel. (H4) 1/2 NPT Male to 3/8" Female Swivel - 90° Elbow.

- b.** Install control valve lever(s) (G5), control valve safety lever (G7), and safety lever return spring (G10), as shown. Secure with cotter pins (G13).




(G5) Control Valve Lever(s). (G7) Control Valve Safety Lever. (G10) Safety Lever Return Spring. (G13) Cotter Pin(s).

4. Attach the main hydraulic hoses.




(G15) Valve to Drive Ram Hose. (G17) Pressure Supply Hose. (G20) Return Hose.

- a.** Apply thread sealant compound to threads and install valve to drive ram hose (1/2" I.D. x 35") (G15) between hydraulic control valve (G1 or H1) and drive cylinder assembly (C1).



(C1) Drive Cylinder Assembly. (G1) Control Valve (Single Lever). (G15) Valve to Drive Ram Hose. (H1) Control Valve (Triple Lever) (not shown).

- b. Apply thread sealant compound to threads and install swivel fitting on pressure hose (3/8" x 120") (G17) to control valve (G1 or H1).
- c. Apply thread sealant compound to threads and install swivel fitting on return hose (3/4" x 120") (G20) to control valve (G1 or H1).




(G1) Control Valve (Single Lever). (G17) Pressure Hose. (G20) Return Hose. (H1) Control Valve (Triple Lever) (not shown).

IMPORTANT NOTICE


If the hoses are attached differently than shown, the control of the drive ram will not be as described in this manual.

- d. Hydraulic tilt base plate only. Apply thread sealant compound to hose fitting threads (cylinder end only) and attach tilt cylinder hoses (H5) between forward tilt cylinder (F3) and triple lever control valve (H1), as shown.



(F3) Forward Tilt Cylinder. (H1) Triple Lever Control Valve. (H5) Tilt Cylinder Hoses.

- e. Apply thread sealant compound to hose fitting threads (cylinder end only) and install side tilt cylinder hoses (F4) between tilt cylinder hose (H5) and triple lever control valve (H1), as shown (hydraulic tilt base plate only).



(F4) Side Tilt Cylinder Hose. (H1) Triple Lever Control Valve. (H5) Tilt Cylinder Hose.

Safety Stop Adjustment

WARNING




To avoid serious injury, inspect the control valve safety stop before using the Post Driver the first time and/or before each daily use.

Adjust the safety stop as needed, per the following procedure. Make sure all control valve hardware is tight. Always replace worn or damaged parts before use.

The control valve safety stop prevents unintentional activation of the Post Driver control valve and must be functional at all times.

If the Post Driver is operational, make sure the machine/power source is off, parking brake is set, road lock pin is installed, and the hydraulic pressure is released (zero).


1. Attempt to push main hydraulic control valve lever (G5) forward (away from operator) without squeezing (pulling) yellow tipped control valve safety lever (G7).



(G5) Main Hydraulic Control Valve Lever. (G7) Control Valve Safety Lever.

2. If main hydraulic control valve lever (G5) **CAN** move forward more than 1/4", the safety stop must be adjusted.


3. To adjust the safety stop, do the following:
 - a. Squeeze the control valve lever and the control valve safety lever together to expose the safety lever stop setscrew.
 - b. Insert a 1/8" Allen wrench and adjust the setscrew outward (counterclockwise) slightly. Remove the Allen wrench and repeat Step 1.



Adjust the Safety Stop Setscrew.

- c. If necessary, repeat Step 3a and Step 3b just until the setscrew prevents more than 1/4" of forward movement of the control valve lever.


NOTE: Do not "over adjust" the setscrew. Make sure the setscrew easily falls into place behind the lip on the control valve when it is released quickly (1/8" gap at the setscrew).



Gap Between Setscrew and Valve Body.

Rubber Debris Guard

1. Locate rubber debris guard (A4), guard mounting strap bracket (A5), and bag containing hardware and caution tag (A6, A7, A8, and A9).



(A4) Rubber Debris Guard. (A5) Guard Mounting Strap Bracket. (A6) Caution Tag. (A7) Bolt. (A8) Lock Washer. (A9) Nut.

2. Attach rubber debris guard, mounting strap, and caution tag on drive ram (A1) with guard mounting bolts, lock washers and nuts, as shown.

IMPORTANT NOTICE

Do not overtighten hardware and damage the rubber debris guard.



(A1) Drive Ram.


Safety Arm

! WARNING



To avoid serious injury or death, the safety arm must be installed after the Post Driver has been mounted on a machine, or the freestanding Post Driver has been secured to prevent tipping.

1. Locate safety arm assembly parts and hardware.




(I2) Safety Arm Frame. (I3) Frame Mounting Bolt. (I4) Self Locking Nut. (I5) Swing Arm Handle. (I6) Roller Bracket. (I7) Roller Retainer Roll Pin. (I8) Roller Bracket Nut. (I9) Spring Retainer Flat Washer. (I10) Lynch Pin. (I11) Hardware.

2. Attach safety arm frame (I2) to outside of short channel bracket (D1 or D2) with two 3/4-10 x 2" frame mounting bolts (I3) and self locking nuts (I4), as shown. Tighten nuts securely.



(D1) Manual Channel Bracket. (D2) Hydraulic Channel Bracket (not shown). (I2) Safety Arm Frame. (I3) Frame Mounting Bolt. (I4) Self Locking Nut.


3. Assemble rollers (I7) onto roller bracket (I6) and secure with two roller retainer roll pins (I8), as shown.



(I6) Roller Bracket. (I7) Roller. (I8) Roller Retainer Roll Pin.


4. Apply a light film of a good quality grease to the pivot shaft and attach roller bracket (I6) to swing arm handle (I5) with roller bracket nut (I9). Tighten nut until seated and then loosen 1/4 to 1/2 turn.

NOTE: Roller bracket (I6) must swivel freely on swing arm handle (I5).




(I5) Swing Arm Handle. (I6) Roller Bracket. (I9) Roller Bracket Nut.

5. Attach one end of latch spring (I10) to swing arm handle (I5), as shown. Secure with spring retainer flat washer (I11) and Lynch pin (I13).




(I5) Swing Arm Handle. (I10) Latch Spring. (I11) Spring Retainer Flat Washer. (I13) Lynch Pin.

6. Install the swing arm assembly.
 - a. Apply a light film of a good quality grease to the pivot shaft on swing arm handle (I5).
 - b. Start the pivot shaft into the main bracket tube, as shown. Slide the open spring eye over the main bracket anchor rod.




NOTE: Swing arm handle (I5) will be below safety arm frame (I2) bracket stop at this point.

- c. Secure with flat washer (I11) and Lynch pin (I13).



(I11) Flat Washer. (I13) Lynch Pin.

7. Pull swing arm handle around toward the Post Driver drive ram I-beam until the swing arm clears (swings past) safety arm frame (I2) bracket stop.




8. Tap swing arm handle shaft up through safety arm frame tube. Install Lynch pin (I13) to secure the swing arm to the safety arm frame.



9. Install Lynch pin to secure swing arm to the safety arm frame.




10. Verify the swing arm handle opens against safety arm frame (I2) stop bracket and closes against back wall of drive ram (A1) I-beam.




(A1) Drive Ram. (I2) Safety Arm Frame.

NOTE: When driving a fence post, the swing arm rollers must contact and hold the fence post in position.

Document Storage Tube



1. If desired, locate the document storage tube in a convenient location on the Post Driver. The photo below shows the tube mounted on the drive ram, but other locations are acceptable.



2. Mark the location of the two mounting holes using the storage tube as a guide.
3. Drill two 3/16" holes.
4. Attach the storage tube with the two pop rivets supplied inside the tube.

Post Driver Operation

Operational Safety Tips


1. Follow all safety information contained in this manual and refer to safety decals located on the Post Driver.
2. Personal safety equipment must be worn at all times during operation, i.e. safety glasses, steel toe shoes, hearing protection, etc.
3. Always stand 45 degrees to the right of the post while the Post Driver is in operation.
4. **Do not** remove any of the Post Driver safety equipment or safety labels.
5. All Post Driver safety equipment must be inspected, maintained, kept in working order, and used during Post Driver operation.
6. **Do Not** place your hand(s) on top of the post when placing the post in the Post Driver or while the Post Driver is operating.
7. Leave the safety arm attachment open when not holding a post, except when transporting the Post Driver.
8. **Do not** remove the hydraulic control valve safety lever stop.
9. Never use the maximum force of the Post Driver until the post being driven is started into the ground and is straight.
10. Use caution when driving small diameter wood or steel posts. Maximum driving impact is not necessary.
11. Always be aware of the environment in which you are operating the Post Driver.
12. **Do not** operate the Post Driver on steep slopes, as this could cause a roll over.
13. Always check for underground utilities, i.e. wires, gas lines, water lines, etc. Call your local utility companies for underground utility locations.
14. Use caution where large rocks or other objects could be hidden underground and not visible to the operator. The post could splinter and cause injury to the operator. If the post fails to drive into the ground after two or three strikes, move to another location.

15. **Do not** operate the Post Driver with machine or power source unattended. The Post Driver requires two people for proper operation - one operating the Post Driver and one on the tractor.
16. Always engage the road lock pin in the drive ram upper hole before transporting and in the lower hole for storage.

Operating Instructions

Mounting

1. With the Post Driver positioned on a hard level surface, move the tractor or other power supply toward the Post Driver until three-point hitch lines up.
2. Attach two lower, three-point hitch lift arms to Post Driver three-point hitch weldment (K1) hitch pins. Secure with lock pins (operator supplied).




(K1) Three-Point Hitch Weldment. (K2) Leg Bracket Weldments. (K8) Stabilizer Leg Lock Bolt.

NOTE: The HD-8 Post Driver will fit tractors with Category I or Category II three-point hitches. Use bushings on hitch pins, if required, to correctly install lift arms.

3. Attach the three-point top link to removable pin in Post Driver three-point hitch weldment (K1). Secure upper pin with Lynch pin.

NOTE: Adjust the length of the machine's top link, as required, to correctly attach the Post Driver.

4. Attach hydraulic pressure supply hose (small diameter, G17) to the tractor pressure supply port. Attach hydraulic return hose (larger diameter, G20) to the tractor return port.



(G1) Control Valve. (G17) Hydraulic Pressure Supply Hose. (G20) Hydraulic Return Hose.

NOTE: The operator is responsible for installing quick-disconnects, return fitting, or other suitable fittings to the Post Driver hoses that are compatible with the tractor.

5. If traveling more than 100 feet to drive the first post, remove road lock pin (B8). Raise drive ram (A1) and install road lock pin in lower "transport" position. The Post Driver can now be moved to the work site.




(A1) Drive Ram. (B8) Road Lock Pin.

Preparing to Drive a Post

IMPORTANT NOTICE


If operating on uneven ground, make sure stabilizer legs firmly contact the ground at each new fence post location. If necessary, loosen stabilizer leg lock bolts to readjust stabilizer legs as needed. Failure to do so can cause damage to Post Driver components.

6. Loosen stabilizer leg lock bolts (K8) and raise up each stabilizer leg (K7). Tighten lock bolts to support stabilizer legs.



(K7) Stabilizer Leg.

7. Position the tractor or power source in place to drive the first fence post.
8. Set the brakes on the tractor or power supply. If the machine is equipped with an automatic transmission, the transmission must be in PARK.
9. Remove road lock pin (B8) and lower drive ram (A1) until it rests on main carriage channel lower rubber bumpers (B3) (store road lock pin in a secure location).



(A1) Drive Ram. (B3) Main Carriage Channel Lower Rubber Bumper. (B8) Road Lock Pin.

10. Lower Post Driver until drive ram (A1) firmly contacts the ground.
 11. Continue to lower Post Driver main carriage channel (B1) an additional 1" (2.5 cm).
- NOTE:** This important step helps protect lower rubber bumpers (B3) from premature wear and/or damage.
12. Loosen stabilizer leg lock bolts and lower stabilizer legs until both feet firmly contact the ground. Tighten stabilizer leg lock bolts.

Driving a Post

13. Lubricate four guide blocks (A2) with oil before each daily use and, if necessary, between post installations.

IMPORTANT NOTICE

Do not use grease on the guide blocks or in the main carriage channel. Grease will retain abrasive material, which will result in premature wear.




NOTE: The tractor or other power source must be capable of maintaining adequate hydraulic pressure (engine RPM) to smoothly operate (cycle) the Post Driver.

WARNING



To avoid personal injury or death, do not operate the Post Driver by yourself. Always have another person to control the machine or power source.

- Open (pull back) safety arm frame (I2) and pull main hydraulic control valve lever (G5) to raise drive ram (A1).







(A1) Drive Ram. (G5) Hydraulic Control Valve Lever. (I2) Safety Arm Frame.

IMPORTANT NOTICE

At the beginning of each day, use the main hydraulic control lever to cycle the drive ram up and down 10 to 15 times, without impact with a post or the ground, to “season” the drive ram return springs. Failure to follow this recommendation can cause damage to the springs.

- If necessary to drive the fence post straight, adjust the main carriage channel side-to-side and fore-and-aft using manual cranks (manual base plate) or second and third hydraulic control valve levers (hydraulic base plate) to activate hydraulic tilt cylinders.




! WARNING



Potential pinch points. Keep hands clear of Post Driver while operating. Never place hand(s) on top of a post when inserting it into the Post Driver. Always close the safety arm when driving the post.

16. Place a fence post in drive ram (A1) I-beam under the drive ram plate.

NOTE: There should be a 1" to 2" gap between the top of the fence post and the bottom of the drive ram plate. The photo below shows the rubber debris guard raised up for photographic purposes. Never drive a fence post without the guard in place.



17. Close safety arm frame (I2) to secure the post (the adjustable roller assembly keeps tension on the post while it is being driven).



(I2) Safety Arm Frame.

18. **Do not** stand in front of the drive ram while operating the Post Driver. Stand at a 45 degree angle to the side of the Post Driver, in front of hydraulic control valve (G1, H1).



19. Squeeze control valve safety lever (G7) and push control valve lever (G5) to release the drive ram and create impact.



(G5) Control Valve Lever. (G7) Control Valve Safety Lever.

20. Pull control valve safety lever and handle to raise drive ram again. Continue this process, as needed, to drive the post to the desired depth.



IMPORTANT NOTICE

Posts will go in the ground much straighter using shorter strokes. Use caution when driving small diameter wood and steel posts. Maximum impact is not necessary with these smaller diameter posts and can cause damage (splintering or breakage) of posts.

NOTE: If the post stops going down or is crooked after a few impacts, stop and move the post to a different location. Conditions such as thick sod, rocks, or tree roots can cause splintered or broken posts.

21. Once a post is driven to the desired depth or the drive ram contacts the ground, release the hydraulic control lever.
22. Open safety arm frame (I2).
23. Raise the Post Driver and move to the next location to begin driving a new post.
24. If traveling more than 100 feet, install road lock pin in lower “transport” position. The Post Driver can now be moved to the next work site or the storage location.

Placing Post Driver into Storage


1. Install road lock pin in upper “storage” position. The Post Driver should be stored on a hard level surface.
2. Lower the drive ram until it is on the ground.




3. Raise or lower the stabilizer legs to allow drive ram I-beam full contact with the ground. Make sure the Post Driver is stable.

NOTE: On units without stabilizer legs, store the unit against a post driven into the ground. Position the unit with the driving ram next to the post and secure with a chain wrapped securely around the post and Post Driver.

4. On hydraulic tilt units, tighten the nut on the cylinder stop bracket to prevent the cylinder from drifting and causing an unstable condition with the Post Driver. Failure to tighten this bolt could allow the Post Driver to fall over, causing serious injury or even death.



5. Make sure pressure is relieved from the Post Driver hydraulic system. Disconnect hydraulic pressure supply hose (G17) from the tractor. Disconnect hydraulic return hose (G20) from the tractor.



(G17) Hydraulic Pressure Supply Hose. (G20) Hydraulic Return Hose. (G1/H1) Control Valve.

6. Remove two lower lift arm and top link lock pins from three-point hitch weldment (K1). Separate three-point hitch from the Post Driver.
7. Carefully move tractor or power source away from the Post Driver.

Troubleshooting

NOTE: Refer to the Service Parts section of this manual for a photo and description of all the parts.

Problem: Drive ram (A1) will not move or slide freely on main carriage channel (B1).

Possible Cause/Solution(s):

1. Guide blocks (A2) lack lubricant. Lubricate with clean engine oil.
2. Guide blocks (A2) installed incorrectly. Refer to Service Information section assembly procedures for correct orientation.
3. Incorrect clearance between main carriage channel (B1) and drive ram (A1) I-beam. Refer to Service Information section for clearance specifications.
4. Hydraulic drive cylinder assembly (C1) is not parallel to main carriage channel (B1). Refer to Service Information section, hydraulic drive cylinder installation, and parallelism adjustment.
5. Main carriage channel (B1) or drive ram (A1) is bent or damaged. Discontinue use and order replacement parts.

Problem: Poor performance, low or no impact, hydraulic drive cylinder will not extend.

Possible Cause/Solution(s):

1. Weak or broken drive ram springs (C14).
2. Broken lower spring bracket (C13).
3. Bent or damaged hydraulic drive cylinder assembly (C1).
4. Main carriage channel (B1) is binding.
5. Restricted or plugged hydraulic hose(s) (G15, G17, G20).
6. Low or no hydraulic pressure or flow from the machine or power source.

Problem: Rubber bumpers (B3) have premature or excessive damage.

Possible Cause/Solution(s):

1. Post Driver is not properly adjusted prior to operation and drive ram guide blocks (A2) are contacting rubber bumpers (B3).

Storage

For the best results, always store equipment in a dry, protected location. Leaving equipment unprotected will shorten the service life of the implement.

1. Before storing, remove debris and clean the entire unit with compressed air or pressure washer.
2. Inspect the Shaver Post Driver.
 - Check all bolted connections. Ensure that fasteners are tight, and all pins are secured in place.
 - Inspect frame for structural fractures.
 - Make sure all warning decals are in place and legible.
 - Make sure rubber debris guard is in place and in serviceable condition.
 - Check hydraulic cylinder(s) for signs of seal damage or excessive wear.
 - Inspect all hydraulic hoses and fittings for leaks or signs of wear.
3. After cleaning, lightly lubricate guide blocks with clean engine oil. Do not apply grease, as this will retain grit and cause excessive wear.
4. Clean and lubricate hydraulic control valve safety stop linkage. Make sure return spring and cotter pins are in good condition.
5. Apply a light coating of clean grease to all exposed hydraulic cylinder shafts to help prevent rust.

Service Procedures

WARNING



To avoid personal injury or death, carefully read and understand all instructions before attempting to assemble and/or operate the Post Driver. Do not operate or work on equipment unless you read and understand the instructions and warnings in this and all other applicable manuals. Contact Shaver Manufacturing Company if any of the instructions provided are unclear or not understood. Proper care is your responsibility. Always follow all State and Federal health and safety laws and/or local regulations.



To help prevent personal injury, protective equipment must be worn during Post Driver assembly, operation, and maintenance. Personal protective equipment should include, but not be limited to, safety glasses, hearing protection, protective gloves, and steel toe footwear.



Before making any adjustments on the Post Driver, ensure that all hydraulic levers are in the neutral position. Always shut off the machine, set parking brake, and remove key before performing any service.



Personal injury can result from slips or falls. DO NOT leave tools or parts laying around the work area, and clean up all spilled fluids immediately.

NOTE: Disassembly, assembly, and/or associated repairs must be performed with the main carriage channel and drive ram in a horizontal position, such as on a suitable pallet, or heavy-duty support stands.

Refer to Dismounting Post Driver from Machine/Power Source section for steps to remove Post Driver from a tractor or other power source.

Three-Point Hitch/Post Driver Disassembly

1. Secure the Post Driver upright (main carriage channel (B1) and drive ram (A1) assembly) to an appropriate overhead lifting device to prevent tipping.
2. Disconnect drive cylinder to valve hose (G15) and drain fluid into a suitable container.
3. On hydraulic base plate models, tighten the cylinder stop arm bolt. Disconnect four tilt cylinder hoses (H5) from hydraulic control valve (H1), and drain fluid into a suitable container.
4. Remove Lynch pin locks and two short channel mounting pins (D6) that connect the base plate to the Post Driver upright (applies to manual or hydraulic models).


NOTE: If necessary, lubricate channel mounting pins with penetrating oil to assist pin removal.

5. With assistance, carefully move the three-point hitch weldment/base plate assembly away from the Post Driver upright. Store weldment/base plate assembly in a safe location.
6. The upright assembly is heavy. Use an appropriate lifting device to position the Post Driver assembly horizontally, on suitable stands, pallet, or blocks on the ground.




Main Carriage Channel Disassembly

1. Remove road lock pin (B8).



(B8) Road Lock Pin.

2. Remove the two 3/8-16 self locking nuts that attach drive cylinder (C2) and lower spring bracket (C13) to main carriage channel (B1).




(B1) Main Carriage Channel. (C2) Drive Cylinder. (C13) Spring Bracket.

3. Push hydraulic drive cylinder assembly (C1) to the closed (retracted) position.

NOTE: Be prepared to collect any hydraulic fluid that drains from the cylinder into a suitable container.


4. Remove upper drive cylinder rod self locking nut (C4) from drive cylinder piston (C3).

NOTE: Do not reuse self locking nut (C4). Replace with a new self locking nut.




(C3) Drive Cylinder Piston. (C4) Self Locking Nut.
(C16) Lock Washer.

- Remove drive ram spring(s) (C14) from the upper spring bracket by creating a loop in the spring.




(C14) Drive Ram Spring(s).

- Remove springs from the bottom of the Post Driver between drive ram (A1) I-beam and main carriage channel (B1).



(A1) Drive Ram. (B1) Main Carriage Channel.


- Inspect upper and lower spring mounting brackets for wear, specifically at spring contact points.
- Inspect springs for wear in and around the spring eyelet area and the full spring length. Check for bent or cracked spring loops.
- Remove two road lock bracket nuts (B7) and remove road lock bracket (B2) from main carriage channel.



(B2) Road Lock Bracket. (B7) Road Lock Bracket Nuts.
(C2) Drive Cylinder.

- Inspect road lock bracket, rubber bumpers, and hardware. Replace as necessary.
 - Remove drive cylinder assembly (C1) by sliding it out the top of main carriage channel (B1).
- NOTE:** Refer to Drive Cylinder Seal Replacement section for cylinder service.
- Get assistance to remove main carriage channel (B1) by sliding it out of drive ram (A1).

13. Remove guide blocks (A2) and shims (A3) from pins inside the drive ram I-beam.




(A2) Guide Blocks. (A3) Shims.

14. Inspect contact points on guide blocks (A2) for excessive wear and replace as necessary.
15. Inspect drive ram (A1) I-beam for wear or damage.

Drive Cylinder Seal Replacement


1. Remove drive ram cylinder assembly (C1) from the Post Driver, as outlined in the disassembly instructions.



(C1) Drive Ram Cylinder Assembly.

2. Be prepared to collect any hydraulic fluid that drains from the cylinder into a suitable container. Unscrew cylinder cap (C7) and remove cylinder piston rod (C3) from the cylinder housing.

NOTE: Care must be taken during removal to prevent scoring of cylinder piston rod (C3) or the inside of the cylinder tube (C2).



(C3) Cylinder Piston Rod. (C7) Cylinder Cap.


3. Inspect threads on the O.D. of drive cylinder (C2) tube and I.D. of cylinder cap (C7). Repair or replace components with damaged threads.

- Remove self locking piston guide nut (C11) and piston rod guide (C10), using a 1-1/4" wrench to hold the piston rod guide while removing the piston guide nut. Discard the self locking nut and replace with new.



(C10) Piston Rod Guide. (C11) Self Locking Piston Guide Nut.

- Place cylinder cap (C7) and cylinder cap seal (C9) in hot (120°F) water for ten minutes. Soaking the cap and seal will make the seal more pliable and easier to remove.
- Wear gloves to protect your hands from hot components, and use a sturdy seal pick to remove cylinder cap seal (C9) from cylinder cap (C8).




(C8) Cylinder Cap. (C9) Cylinder Cap Seal.

- Clean the seal groove in cylinder cap (C8) and place the new seal in hot (120°F) water for ten minutes.

- Once the seal is pliable, squeeze the new seal together making a banana shape. Place one end of the seal into the cylinder cap seal groove. Continue to push the seal into the seal groove, holding the seal in the groove from the bottom with one finger, while continuing to push the seal down from the top until the seal snaps in place.

IMPORTANT NOTICE

Care must be taken not to damage the new seal while installing it. Do not use a sharp tool, such as a screwdriver, to push the seal into place. A suitable diameter impact socket with rounded edges can be useful in pushing the seal into the cap groove.



(C8) Cylinder Cap. (C9) Cylinder Cap Seal.

- Once cylinder cap seal (C9) is in the groove, double check for correct orientation. The sharp edge of the seal must be down (towards the threads inside cap).
- Lubricate the seal with clean hydraulic fluid and slide the cap onto cylinder piston rod (C3) from the **bottom**.

IMPORTANT NOTICE

Do not slide the cylinder rod cap over the top of the drive cylinder rod. The threads will damage the new cylinder rod cap seal.

11. Install piston guide (C10) and new self locking piston guide nut (C11), using a 1-1/4" wrench to hold the piston guide while installing the piston guide nut. Do not overtighten the self locking nut. Piston guide (C10) must be able to rotate on cylinder piston rod (C3).
12. Install cylinder piston rod (C3) assembly into drive cylinder tube (C2).

NOTE: Care must be taken during installation to prevent scoring of cylinder piston rod (C3) or the inside of the drive ram cylinder tube (C2).

13. Apply paste-type thread sealer on drive cylinder tube (C2) external threads and install cylinder cap assembly (C7). Tighten cap securely.

IMPORTANT NOTICE

All hydraulic system fittings must be installed with a paste-type thread sealant only. Do not use a tape-type sealer such as Teflon Tape, as this can contaminate the system and voids the valve warranty.

14. To install drive cylinder assembly (C1) in the Post Driver, follow the instructions in the Main Carriage Channel Assembly section.

Main Carriage Channel Assembly

1. Install shims (A3) and guide blocks (A2) on the pins inside drive ram (A1) I-beam.


NOTE: Chamfer (rounded edges) on guide blocks must be positioned horizontally to match the chamfer on the inside of main carriage channel (B1) frame.

2. Lubricate guide blocks with clean oil to reduce friction. With assistance, install (slide) main carriage channel (B1) over guide blocks (A2).

3. Main carriage channel should slide back and forth freely without contacting or rubbing drive ram.
4. With assembly horizontal, check up and down movement of main carriage channel in drive ram I-beam. Up and down movement should not be less than a 1/4" or more than 1/2".
5. Install drive ram cylinder assembly (C1) in main carriage channel (B1) from the top (upper end).
6. Install springs (C14) from the bottom of the Post Driver between drive ram (A1) I-beam and main carriage channel (B1), and slide into position.


NOTE: Hydraulic drive ram cylinder (C1) must be installed in main carriage channel (B1) before springs (C14) are installed.

7. Hook springs (C14) to the upper spring bracket by creating a loop in the spring. Make sure the spring eyelets are completely seated in the bottom of the bracket slot.



(C14) Springs.

8. Attach drive cylinder piston rod (C3) to the top of the drive ram I-beam using a new lock washer (C16) and self locking nut (C4).



(C3) Drive Cylinder Piston Rod. (C4) Self Locking Nut. (C16) Lock Washer.


9. Hold the lower nut with a 1-1/8" wrench and tighten self locking nut using 1-1/16" wrench. Then loosen self locking nut 1/2 turn (180 degrees).

NOTE: The adjustment in Step 10 allows for better alignment of the drive ram cylinder within the main carriage channel.




Loosen Lock Nut (C4) 1/2 Turn After Tightening.

10. Install rubber bumpers (B3) on road lock bracket (B2). Install assembly on bottom of main carriage channel (B1) using two 3/8-16 x 2" bolts (B6) and 3/8-16 nuts (B7). Tighten the nuts completely.



(B1) Main Carriage Channel. (B2) Road Lock Bracket. (B3) Rubber Bumper. (B6) Bolt. (B7) Nut.

11. Place lower spring bracket (C13) (not visible) against hydraulic drive cylinder assembly (C1) bottom plate and align bolt openings. Extend the drive cylinder and lower spring bracket downward and install both bottom plates on mounting bolts (B6) using two new 3/8-16 self locking nuts (C12).



(C1) Hydraulic Drive Cylinder Assembly. (C12) Self Locking Nuts.

12. To avoid binding, the drive cylinder and rod must be parallel to the sides of the main carriage channel. If necessary, make the following adjustments:
 - a. Make sure the top drive ram cylinder self locking nut is loosened 1/2 turn.
 - b. Loosen the lower drive ram cylinder self locking nuts.
 - c. Tighten each nut slightly, in turn, to align the drive cylinder inside the main carriage channel.
13. Pull main carriage channel (B1) down and install road lock pin (B8) and Lynch pin (B9) in lower hole in drive ram (A1).

Forward and Side Tilt Cylinder Maintenance


Cylinder Disassembly

1. Remove cylinders (F3 or F4) from base plate by disconnecting and plugging the hydraulic hoses and removing two mounting pins (F7 and/or F8).

NOTE: Be prepared to collect any hydraulic fluid that drains from the cylinder and hoses into a suitable container.


2. Plug cylinder fittings, and clean the outside of the tilt cylinder.
3. Inspect the cylinder mounting points. Replace any worn or damaged components.

4. Carefully clamp cylinder (F3 or F4) mounting tube in a vise. Completely compress internal cylinder cap snap ring (F14) and pull cylinder rod assembly (F16 or F17) out of tilt cylinder tube (F21).



(F3/F4) Cylinder (forward or side tilt). (F14) Internal Cylinder Cap Snap Ring. (F16) Cylinder Rod Assembly.

5. Disassemble cylinder rod (F16 or F17) by removing cylinder rod nut (F20), piston (F19), piston to cylinder rod seal (F18), and cylinder cap (F15) from the cylinder rod.




(F15) Cylinder Cap. (F16 or F17) Cylinder Rod. (F18) Cylinder Rod Seal. (F19) Piston. (F20) Cylinder Rod Nut.

6. Inspect cylinder rod sealing surface for any dents, bends, nicks, pitting, scratches, scoring, or rust. Replace any worn or damaged components.
7. Disassemble cylinder cap and inspect components. Replace any worn or damaged components.

8. Disassemble cylinder piston and inspect components. Replace any worn or damaged components.
9. Clean the inside of the tilt cylinder tube and inspect for scratches with raised (above the surface level) edges, wear, rust, cracks, and pitting. Replace any worn or damaged components.

Cylinder Assembly


1. Make sure all tilt cylinder components are free of rust and clean using a lint free rag.
2. Use a sturdy seal pick to remove the old seals and discard. Lubricate new seals with clean hydraulic fluid.
3. Install new internal O-ring seal (F23) and lip seal (F24) (raised lip up) inside the cylinder cap. Install a new O-ring seal (F22) in the O.D. groove. Install a new snap ring (not shown) in the top "cut-a-way" groove.



(F22) External O-ring Seal. (F23) Internal O-ring Seal.
(F24) Internal Lip Seal.


4. Install new scraper seal (F25) in the cylinder piston groove, followed by O-ring seal (F26), and the second scraper seal (F25).

NOTE: The rounded surface of each scraper seal (F25) must face (contact) the larger O-ring seal (F26).




(F25) Scraper Seal. (F26) O-ring Seal.

5. Install new slender O-ring seal (F18) on the threaded end of cylinder rod (F16 or F17).
6. Lubricate the ID of cylinder piston (F19) and cylinder cap (F15) with clean hydraulic oil.
7. Install cylinder cap (F15) onto cylinder rod (F16 or F17) with the snap ring groove facing up (toward the cylinder rod mounting eye).
8. Install cylinder piston (F19) with the O-ring relief (groove) toward slender O-ring seal (F18) on cylinder rod (F16 or F17). Install new self locking nut (F20) and tighten securely.



(F15) Cylinder Cap. (F16 or F17) Cylinder Rod.
(F18) O-ring Seal. (F19) Cylinder Piston (with seal).
(F20) Self Locking Nut.

- Lubricate cylinder tube (F21) bore, piston (F19) seals, and cylinder cap (F15) seals. Install cylinder rod (F16) assembly into the cylinder tube, being careful not to damage any seals.



(F16 or F17) Cylinder Rod. (F21) Cylinder Tube.

- Push cylinder rod (F16 or F17) into cylinder tube (F21) until snap ring (F14) in piston groove contacts the top of the tube.
- Use heavy-duty snap ring pliers to completely compress snap ring (F14). Push cylinder cap (F15) into cylinder tube (F21) until the snap ring is engaged inside the tube.

! WARNING




Make sure snap ring is completely seated in cylinder tube groove. Failure to seat snap ring in groove can cause the cylinder cap to be explosively ejected from the tilt cylinder tube when hydraulic pressure is applied, resulting in serious injury or even death.

- Continue pushing cylinder cap (F15) into cylinder tube (F21) until snap ring (F14) is completely seated in the cylinder tube snap ring groove.

NOTE: It may be necessary to use a soft (brass or wood) drift to tap the cylinder cap and snap ring into place. Use caution not to damage the aluminum cylinder cap.

- Install the tilt cylinder assembly on the base plate with mounting pins (F7 and/or F8) and Lynch pins. Reconnect hydraulic hoses (H5).



(F7) Mounting Pin. (F8) Mounting Pin. (H5) Hydraulic Hoses.

Three-Point Hitch/Post Driver Assembly

1. With road lock pin (B8) installed in the lower hole of drive ram (A1), use a suitable overhead lifting device to raise (stand up) main carriage channel assembly (B1).



(A1) Drive Ram. (B1) Main Carriage Channel Assembly.
(B8) Road Lock Pin.


⚠ WARNING

The main carriage channel assembly is tall and heavy. To avoid tip over, resulting in serious injury or death, leave the overhead lifting device attached to the main carriage channel while assembling components.

2. To assemble three-point hitch and Post Driver upright assembly after service, refer to Step 3 through Step 5 in the Assembly Procedure, Base Plate section in this manual.

Service Parts

Driver Assembly



Driver Assembly

HD-8 Service Parts - Driver Assembly			
Item No.	Part No.	Description	Qty.
A1	SM-0011-DRC	Driving Ram Complete Unit	1
	SM-0011-DRO	Driving Ram Only	1
	SM-0011-MRO	Driving Ram Vineyard ¹	
A2	SM-00512	Guide Block	Pkg. of 4
A3	SM-0933-(18 ga)	Shim	4
	SM-9034-(14 ga)		
	SM-0935-(10 ga)		
A4	SM-0011-G	Rubber Debris Guard ²	1
A5		Guard Mounting Strap	1
L8		Caution Tag	1
A7		Guard Mounting Bolt	3
A8		Guard Mounting Washer	3
A9		Guard Mounting Nut	3
B1	SM-00412	Main Carriage Channel	1
B2	SM-0041-RLB	Road Lock Bracket (no pin)	1
B3	SM-0041-B	Rubber Bumper ³	4
B4		Bumper Nut, 5/16"-18	4
B5		Bumper Lock Washer, 5/16"	4
B6	SM-02612	Road Lock Bracket Bolt	2
B7	SM-02614	Road Lock Bracket Nut	2
B8	SM-1041-RLP	Road Lock Pin	1
B9	SM-1041-RLC	Road Lock Pin Clip	1
C1	SM-0263	Cylinder Assembly	1
C2	SM-0264	Cylinder Tube	1
C3	SM-0266	Cylinder Piston/Rod	1
C4	SM-0267	Piston Self Locking Nut	1
C5	SM-018	Cylinder Nut (with setscrew)	1
C6	SM-0268	Lock Washer	1
C7	SM-0262-D	Cylinder Cap (with seal)	1
C12	SM-02613	Lower Spring Bracket Lock Nut	2
C13	SM-0011-SBL	Lower Spring Bracket	1
C14	SM-0011-DRS	Spring (with clips installed)	2
C15	SM-0011-SC	Spring Clip Only	4

HD-8 Service Parts - Driver Assembly (continued)			
Item No.	Part No.	Description	Qty.
D3	S-012	Short Bracket Bolts 5/8-11 x 1-1/4"	4
D4	S-013	Short Bracket Lock Washer 5/8"	4
D5	—	Short Bracket Nut, 5/8"-11	4
L2	MS-161	Large "SHAVER" Decal	1
L3	MS-169	Control Valve Decal	1
L5	MS-181	Pinch Area Warning Decal	1
L7	MS-280	FEMA Member Decal	1
L9	MS-180	Cylinder Shaft Loose Decal (not visible)	1

¹ Special U-Shaped Ram for Vineyard Application.

² SM-0011-G Includes Items A5, L8, A7, A8, and A9.

³ SM-0041-B Includes Items B3, and B5.


Driving Ram Weldment Parts



HD-8 Service Parts - Driving Ram Weldment			
Item No.	Part No.	Description	Qty.
A10	SM-0011-BS	Guide Pins. ¹	4
A11	SM-0011-SBU	Upper Spring Bracket. ¹	1
A12	SM-0011-LYB	Lift Yoke Bar. ¹	1
A13	SM-0011-LYTS	Lift Yoke Top. ¹	1

¹ Replacement Of These Parts Requires Removal Of Old Parts With A Cutting Torch And/Or Grinding Wheel. New (Replacement) Parts Must be Welded To Driving Ram. This Type Of Repair Voids Any Warranties.

Manual Base Plate Assembly



HD8-64

Manual Base Plate Assembly

HD-8 Service Parts - Manual Base Plate Assembly			
Item No.	Part No.	Description	Qty.
D1	SM-001	Short Channel (manual)	1
D6	SM-014	Channel Mounting Pin	2
D7	SM-2025-LP	Lynch Pin	4
E1	SM-015-BPC	Complete Base Plate Assembly ¹	1
E2	SM-015	Manual Base Plate	1
E3	SM-016	Side Tilt Crank	1
E4	S-20	Flat Washer	1
E5	SM-017	Side Tilt Crank Sleeve	1
E6	SM-018	Side Tilt Crank Nut (with setscrew)	1
E7	SM-2025-SB	Side Tilt Crank Screw Block	1
E8	—	Screw Block Mounting Bolt, 5/16-18 x 3"	1
E9	—	Screw Block Lock Washer 5/16"	1
E10	—	Screw Block Mounting Nut, 5/16-18	1
E11	SM-019	Forward Tilt Crank	1
E12	SM-021	Forward Tilt Nut (with setscrew) ²	1
E13	SM-022	End Tilt Tee	1
E14	—	Base Plate Mounting Bolt, 1/2-13 x 1-1/2" ³	4
E15	—	Base Plate Flat Washer, 1/2" ³	4
E16	—	Base Plate Lock Washer, 1/2" ³	4
E17	—	Base Plate Mounting Nut, 1/2-13 ³	4
E18	SM-015-CC	Crank Handle Cover	2
E19		Crank Screw Block Support	1
G1	P-5000	Hydraulic Control Valve	1
	P-5001	Seal Kit for P-5000 Valve (not shown)	1
G2	—	Valve Mounting Bolt, 5/16-18 x 2-1/2"	3
G3	—	Valve Mounting Washer, 5/16"	3
G4	—	Valve Mounting Nut, 5/16-18	3
G5	P5003	Control Valve Lever (with Safety Handle)	1
G6	—	Control Valve Lever Knob	1


¹ Includes Short Channel, Pins, Cranks, Stops, Etc.

² Or S-095 Nut (with setscrew).

³ S-092 Kit Includes Items E14, E15, E16, and E17.

NOTE: All hardware is Grade 5.

Hydraulic Base Plate Assembly



HD8-65

Hydraulic Base Plate Assembly

HD-8-H Service Parts - Hydraulic Base Plate Assembly			
Item No.	Part No.	Description	Qty.
D2	HBP-909	Short Channel (hydraulic)	1
D6	SM-014	Channel Mounting Pin	2
D7	SM-2025-LP	Lynch Pin	10
E14	—	Base Plate Mounting Bolt, 1/2-13 x 1-1/2" ¹	4
E15	—	Base Plate Flat Washer, 1/2" ¹	4
E16	—	Base Plate Lock Washer, 1/2" ¹	4
E17	—	Base Plate Mounting Nut, 1/2-13 ¹	4
F1	HD-8-HCK	Hydraulic Conversion Kit ²	1
F2	HBP-90811	Hydraulic Base Plate	1
F3/F4	HBP-908120	Cylinder Kit Complete ³	1
F3	HBP-90812	Forward Tilt Cylinder	1
F4	HBP-90813	Side Tilt Cylinder	1
F5	HBP-908131	Cylinder Seal Kit (Fwd & Side)	1
F6	HBP-908132	90° Fittings ⁴	4
F7	HBP-908133	Cylinder Mounting Pin	2
F8	HBP-908134	Side Tilt Mounting Pin	1
F9	—	Cylinder Stop Plate, 8.5" ⁵	1
F10	—	Cylinder Stop Plate, 10.5" ⁵	1
F11	—	Cylinder Stop Bolt, 1/2-13 x 1-3/4" ⁵	1
F12	—	Cylinder Stop Lock Washer, 1/2" ⁵	1
F13	—	Cylinder Stop Nut, 1/2-13 ⁵	1
H2	P-5300	Hydraulic Control Valve	1
—	P-5301	Seal Kit for P-5300 Valve (not shown)	1
H5	SM-02111-P	Tilt Cylinder Hose	4
L10	MS-171	High Pressure Warning Decal	2

¹ HD-8-HCK Kit Includes Items D2, F2, and HBP-908120 Kit.

² HBP-908120 Kit Includes Items F3, F4, and F9 Through F13.


³ S-092 Kit Includes Items E14, E15, E16, and E17.

⁴ Not Used On All Models.

⁵ HBP-908-CS Kit Contains Items F9, F10, F11, F12, and F13.

NOTE: All hardware is Grade 5.


Three-Point Hitch Assembly



HD-8 Service Parts - Three-Point Hitch Assembly

Item No.	Part No.	Description	Qty.
B8	SM-1041-RLP	Upper Link Hitch Pin	1
B9	SM-2025-LP	Lynch Pin	1
K1	MB-01-A	Three-Point Hitch Weldment	1
K2	OS-4-22SFB	Leg Bracket Weldment	2
K3	—	Leg Brkt Bolt, 1/2-13 x 4"	2
K4	—	Leg Brkt Flat Washer, 1/2"	2
K5	—	Leg Brkt Lock Washer 1/2"	2
K6	—	Leg Bracket Nut, 1/2-13	2
K7	OS-4-22	Stabilizer Leg	2
K8	—	Stabilizer Leg Lock Bolt, 5/8-11 x 1-1/2"	2

Safety Arm Assembly




HD-8 Service Parts - Safety Arm Assembly

Item No.	Part No.	Description	Qty.
I1	SM-0011-SAA	Safety Arm Attachment ¹	1
I2	SM-0011-SAAC	Safety Arm Frame	1
I3	—	Frame Mounting Bolt, 3/4-13 x 2"	2
I4	—	Self Locking Nut, 3/4-13	2
I5	SM-0011-SAAD	Swing Arm Handle	1
I6	SM-0011-SAA15	Roller Holder Swivel ²	1
I7	SM-0011-SAA16	Roller ²	2
I8	—	Roller Retainer Roll Pin ²	2
I9	—	Roller Bracket Nut, 3/4-13	1
I10	SM-0011-SAA2	Latch Spring	1
I11	SM-0011-SAA7	Flat Washer, 3/4"	2
I12	SM-015-CC	Swing Arm Handle Cover	1
I13	SM-2025-LP	Lynch Pin, 3/16 x 1-7/8"	3
L1	MS-165	Small "SHAVER" Decal	1
L4	MS-166	Safety Arm Decal	1
L6	MS-181	Pinch Area Warning Decal	1

¹ Complete Safety Arm Kit (parts I2 through L6).

² SM-0011-SAA13C Includes Items I6, I7, and I8.

Hydraulic Hoses



HD-8 Service Parts - Hydraulic Hoses

Item No.	Part No.	Description	Qty.
G15	SM-023-P	Valve to Drive Ram Hose ¹	1
G17	SM-024-P	Power Supply to Valve Hose ²	1
G20	SM-025-R	Valve to Tank Return Hose ³	1

¹ 1/2" ID x 35" long. ² 3/8" ID x 120" long.

³ 3/4" ID x 120" long.

Replacement Decals



HD-8 Service Parts - Replacement Decals			
Item No.	Part No.	Description	Qty.
L1	MS-165	Small SHAVER Decal	1
L2	MS-161	Large SHAVER Decal	1
L3	MS-169	Control Valve Decal	1
L4	MS-166	Safety Arm Decal	1
L5	MS-163	Pinch Area Warning Decal	1
L6	MS-181	Pinch Point Warning Decal	1
L7	MS-280	FEMA Member Decal	1
L8	SM-0011-ST	Caution Tag	1
L9	MS-180	Cylinder Shaft Loose Decal	1
L10	MS-171	High-Pressure Warning Decal	1


Document Tube



HD-8 Service Parts - Document Tube			
Item No.	Part No.	Description	Qty.
J1	ODMAN	Document Tube (with rivets)	1

Hydraulic Control Valves

Single Control Lever Valve




HD-8 Service Parts - Single Control Lever Valve

Item No.	Part No.	Description	Qty.
G1	P-5000	Control Valve (Complete)	1
G5	P-5003	Control Valve Lever Kit ¹	1
G7	GS-001	Control Valve Safety Lever	1
G8	GS-001-2	Safety Lever Plastic Cap	1
G9	—	Safety Lever Stop Setscrew	1
G10	GS-001-3	Safety Lever Return Spring	1
G11	—	Lever Clevis Pin (short)	1
G12	—	Lever Clevis Pin (long)	1
G13	—	Cotter Pin (not shown)	3
G14	P-5007	Closed Center Plug Kit ²	1
G16	HPB-908182	Pipe Fitting, 1/2" NPT 90° Elbow	1
G18	HPB-908183	Fitting, 3/4" to 3/8" NPT Reducer	1
G19	—	Pipe Fitting, 3/8" NPT 90° Elbow	1
G21	HPB-908184	Pipe Fitting, 3/4" NPT 90° Elbow	1
	P-5001	Seal Kit for P-5000 Valve	1


¹ P-5003 Kit Includes Items G7 through G13.

² Not Shown. Provides for "closed center" valve operation.

Expanded View Of Safety Lever Assembly



Triple Control Lever Valve



HD-8-H Service Parts - Triple Control Lever Valve

Item No.	Part No.	Description	Qty.
H1	P-5300	Control Valve (Complete)	1
H3	HBP-9101713	Restrictor Fitting, 1/2" NPT Male to 1/2" NPT Female Swivel	4
H4	HBP-908181	90° Hose Fitting, 1/2" NPT Male to 3/8" Female Swivel	4
G5	P-5003	Control Valve Lever (Section 1)	1
G6	P-5303	Control Valve Lever (Section 2 and 3)	2
G7	GS-001	Control Valve Safety Lever ¹	1
G8	GS-001-2	Safety Lever Plastic Cap ¹	1
G9	—	Safety Lever Stop Setscrew ¹	1
G10	GS-001-3	Safety Lever Return Spring ¹	1
G11	—	Lever Clevis Pin (short) ¹	3
G12	—	Lever Clevis Pin (long) ¹	3
G13	GS-001-5	Cotter Pin ¹	7
G14	P-5007	Closed Center Plug Kit ²	1
G16	HBP-908182	Pipe Fitting, 1/2" NPT 90° Elbow	1
G18	HBP-908183	Fitting, 3/4" to 3/8" NPT Reducer	1
G19	—	Pipe Fitting, 3/8" NPT 90° Elbow	1
G21	HBP-908184	Pipe Fitting, 3/4" NPT 90° Elbow	1
H5	P-5301	Seal Kit for P-5300 Valve	1


¹ Part of P-5003 Handle Kit (Section 1).

² Not Shown. Provides for "closed center" valve operation.

NOTE: For more information on hydraulic valve parts, contact the following suppliers:

- Gresen valve (painted red):
Parker Hannifin Corporation
Phone (440)-366-5200
- Prince valve (painted black):
Prince Manufacturing Corporation
Phone (605) 235-1220

Drive Cylinder Assembly




HD8-73

HD-8 Service Parts - Drive Ram Cylinder Assembly

Item No.	Part No.	Description	Qty.
C1	SM-0263	Drive Ram Cylinder (Complete)	1
C2	SM-0264	Drive Ram Cylinder Tube	1
C3	SM-0266	Drive Ram Cylinder Piston Rod	1
C4	SM-0267	Self Locking Nut	1
C5	SM-018	Nut With Setscrew	1
C6	SM-0268	Spring Lock Washer	1
C7	SM-0262-D	Cylinder Cap With Seal	1
C9	SM-0265-D	Cylinder Cap Seal Only	1
C10	SM-02610	Piston Rod Guide	1
C11	SM-0269	Self Locking Piston Guide Nut	1

Tilt Cylinder Assembly



HD8-74


HD-8-H Service Parts - Fwd & Side Tilt Cylinder Assembly

Item No.	Part No.	Description	Qty.
F3	HBP-90812	Forward Tilt Cylinder ¹	1
F4	HBP-90813	Side Tilt Cylinder ¹	1
F5	HBP-908131	Tilt Cylinder Seal Kit ²	
F14	HBP-908139	Snap Ring	1
F15	HBP-908136	Tilt Cylinder Cap/Gland	1
F16	HBP-90813-A	Side Tilt Cylinder Rod	1
F17	HBP-908121	Forward Tilt Cylinder Rod	1
F18	—	O-Ring Seal ³	1
F19	HBP-908137	Cylinder Piston	1
F20	HBP-908138	Piston Rod Self Locking Nut	1
F21	HBP-90809	Fwd. Tilt Cylinder Tube Only	1
F22	—	External O-Ring Seal ³	1
F23	—	Internal O-Ring Seal ³	1
F24	—	Internal Lip Seal ³	1
F25	—	Scraper Seal ³	2
F26	—	O-Ring Seal ³	1
F27	HBP-90810	Side Tilt Cylinder Tube Only	1
L10	MS-171	High-Pressure Warning Decal	1


¹ Complete Tilt Cylinder-New Design (Elbow Fittings Not Required).

² Not Shown.

³ Part of HBP-908131 Seal Kit (F5).



HD8-58



HD8-59



Shaver Manufacturing Co., LLC.
103 South Washington Avenue
P.O. Box 358
Graettinger, IA 51342
Phone: (712) 859-3293
Fax: (712) 859-3294
sales@shavermfg.com

Limited Warranty

Shaver Manufacturing Company, LLC warrants each new Shaver product to be free from defects in material and workmanship. This warranty is applicable only for the normal service life expectancy of the product or components, not to exceed 12 consecutive months from the date of delivery of the new Shaver product to the original purchaser.

Genuine Shaver replacement parts and components will be warranted for 90 days from the date of purchase, or the remainder of the original equipment warranty period, whichever is longer.

Rubber Bumpers, Carbide Teeth, Auger Teeth and Auger Points are usable parts and not covered by warranty. Part No. SD-101-GB and SD-0301-GB Gearbox are warranted for 3 years from the date of purchase. Part No. SD-0607-GB and SD-0907-GB Gearbox are warranted for 5 years from the date of purchase. Part No. SL-2030-1 5" Cylinder for the Logsplitter is warranted for 4 years from the date of purchase. Driving Ram Springs are warranted for 60 days from the date of purchase for residential customers and 30 days from the date of purchase with a limit of 2 claims per serial numbered unit for commercial users. Tires are warranted for 90 days from the date of purchase.

Under no circumstances will it cover any merchandise or components thereof, which, in the opinion of the company, have been subjected to misuse, unauthorized modification, alteration, an accident, or if a repair has been made with parts other than those obtainable through Shaver.

Our obligation under this warranty shall be limited to repairing or replacing any part that, in our judgment, shall show evidence of such defect, provided further that such part shall be returned within thirty (30) days from the date of failure to Shaver, routed through the dealer and distributor from whom the purchase was made, transportation charges prepaid. All returned items must have an RGA number. Contact Shaver at 712-859-3293 to get authorization to return, file your warranty claim and, if needed, an RGA will be provided.

This warranty shall not be interpreted to render Shaver liable for injury or damages of any kind or nature to person or property. This warranty does not extend to the loss of crops, loss because of delay in harvesting, or any expense or loss incurred for labor, substitute machinery, rental, or for any other reason.

Except as set forth above, **Shaver shall have no obligation or liability of any kind on account of any of its equipment and shall not be liable for special or consequential damages. Shaver makes no other warranty, expressed or implied, and specifically, Shaver disclaims any implied warranty of merchantability or fitness for a particular purpose. Some states or provinces do not permit limitations or exclusions of implied warranties or incidental or consequential damages, so the limitations or exclusion in this warranty may not apply.**

This warranty is subject to any existing conditions of supply which may directly affect our ability to obtain materials or manufacture replacement parts.

Shaver reserves the right to make improvements in design or changes in specifications at any time, without incurring any obligation to owners of units previously sold.

No one is authorized to alter, modify, or enlarge this warranty, nor the exclusion, limitations, and reservations.

Effective January 1, 2009

Warranty Card

The Post Driver is shipped from the factory with a warranty card. If the card is lost or misplaced, please copy this page, fill in the information, and send it to Shaver Manufacturing Company.

Warranty Card

Please complete the warranty card and return to:

Shaver Manufacturing Company
103 South Washington Avenue
P.O. Box 358
Graettinger, Iowa 51342

Purchase / Deliver Date _____

Serial Number _____

Model Number _____

Notes





Operators & Parts Manual



Hydraulic Post Driver

Model HD-8-S, HD-8-H-S,
Model HD-10-S, HD-10-H-S,
& Model HD-12-H-S

Safety

Operation

Maintenance

Repair

Troubleshooting

Parts

2015 and Newer Drivers

Contents

Safety.....	3	Service Procedures.....	32
General.....	4	Dismounting Post Driver from Base Plate.....	32
Safety Alert Symbols.....	4	Post Driver Disassembly.....	33
Safety Icon Nomenclature.....	5	Seal Replacement.....	34
Safety Warnings.....	6	Spring Replacement.....	34
General Safety.....	6	Guide Block/Roller Replacement.....	35
Hazard Avoidance.....	6	Post Driver Reassembly.....	35
Hydraulic Hoses.....	7	Forward and Side Tire Cylinder Seal	
Introduction.....	8	Replacement.....	38
Product Information.....	8	Three-Point Hitch/Post Driver Assembly . .	38
Specifications.....	8	Storage.....	39
Safety Sign Locations.....	9	Troubleshooting.....	40
Safety Signs.....	10	Service Parts.....	42
Assembly Procedure.....	11	Driver Assembly.....	42
Unpacking.....	11	HD-8/HD-10 Ram.....	42
Assembly.....	11	HD-12 Ram.....	44
Mounting Instructions.....	12	Driver Assembly- Springs.....	46
Front-Mounted.....	12	HD-8/HD-10 Springs.....	46
Front-Mounted Main Carriage Channel..	12	HD-12 Springs.....	47
Mounting Instructions.....	13	Driver Assembly- Road Locks & Cushion	49
Rear-Mounted (3-Point).....	13	HD-8/HD-10/HD-12 Road Lock.....	49
Self-Contained Mounting Package.....	14	HD-8/HD-10/HD-12 Rubber Bumpers .	49
Base Plate.....	15	Rubber Guard Assembly.....	50
Attaching Driver to Base Plate.....	15	Safety Arm Assembly.....	51
Connection to Hydraulic Supply.....	16	Manual Base Plate Assembly.....	52
Hydraulic Valve & Hose Installation.....	17	HD-8/HD-10 Manual Base Plate.....	52
Single Lever Control Valve for Hydraulic		Hydraulic Base Plate Assembly.....	54
Manual Plate.....	18	HD-8/HD-10 Hydraulic Base Plate.....	54
Triple Lever Control Valve for Hydraulic		HD-12 Hydraulic Base Plate.....	55
Base Plate.....	19	Manual Base Plate Valve & Hose Ass'y...	56
Rubber Debris Guard.....	20	Hydraulic Base Plate Valve & Hose Ass'y	57
Safety Arm Assembly.....	20	3-Point Hitch Assembly.....	58
Document Storage Tube.....	22	HD-8 3-Point Hitch CAT I.....	58
Attachment and Option Assembly.....	22	HD-10/HD-12 3-Point Hitch CAT II.....	58
Concrete Breaker Accessory.....	22	Stand Package.....	59
Steel Post Holders Accessory.....	22	HD-10/HD-12 3-Point Hitch CAT III.....	59
Post Driver Operation.....	23	Skid Loader Mounting Assembly.....	60
Operational Safety Tips.....	23	Hydraulic Control Valves.....	61
Operating Instructions.....	24	Single Control Lever Valve.....	61
3-Point Hitch Mounting.....	24	Multiple Control Lever Valves.....	61
Self-Contained Mounting.....	25	Self-Contained Hydraulics.....	62
Preparing to Drive a Post.....	25	Pump/Motor Kit.....	62
Driving a Post.....	26	Mounting Package less Bracket.....	62
Dismounting Post Driver.....	30	Pump/ Motor Kit.....	63
		Driver Cylinder Assembly.....	64

Attachments-Pilot Augers	65
Auger Assembly 4" & 6"	65
6" Auger Fish Tail & Tooth Assembly ..	66
Motor & Hose Assembly	67
Motor Mount Plate Assembly	67
Attachments-Concrete Breakers	68
Attachments-Steel Post Holders.....	69
Attachments-Post Holders.....	69
Replacement Decals	70
Limited Warranty	70
Warranty Card.....	72

Safety

Most work related accidents are caused by failure to observe basic safety rules or precautions. An accident can often be avoided by recognizing potentially hazardous situations before an accident occurs. As you assemble and operate the Shaver Post Driver, you must be alert to potential hazards. You should also have the necessary training, skills, and tools to perform this assembly procedure.

Improper operation and maintenance of this implement could result in a dangerous situation that could cause injury or death.

Do not assemble, operate, or maintain the Shaver Post Driver until you read and understand the information contained in this manual.



Safety precautions and warnings are provided in this manual and on the product. If these hazard warnings are not heeded, bodily injury or death could occur to you or to other persons.

Safety

General

Safety of the operator and bystanders is one of the main concerns in designing and developing a new piece of equipment. Designers and manufacturers build in as many safety features as possible. However, every year many accidents occur, which could have been avoided by a few seconds of thought and a more careful approach to handling the equipment.

Most work-related accidents are caused by failure to observe basic safety rules or precautions, neglect, or carelessness. An accident can often be avoided by recognizing potentially hazardous situations before an accident occurs. As you operate, or maintain the unit, you must be alert to potential hazards. You should also have the necessary training, skills, and tools to perform any assembly or maintenance procedures.

Only properly trained people should operate this machine. Improper operation and maintenance of this unit could result in a dangerous situation that could cause injury or death.

If you have any questions not answered in this manual or require additional copies or the manual is damaged, please contact your dealer or

Shaver Manufacturing Company
103 South Washington Avenue
P.O. Box 358
Graettinger, Iowa
51342

Phone: (712) 859-3293
Fax: (712) 859-3294
Website: www.shavermfg.com
E-mail: sales@shavermfg.com

WARNING



Do not use the unit until you read and understand the information contained in this manual.



Safety precautions and warnings are provided in this manual and on the unit. If these warning instructions are not followed, bodily injury or death could occur to you or to other persons.

Shaver Manufacturing Company cannot anticipate every possible circumstance that might involve a potential hazard. The warnings in this manual and on the unit are, therefore, not all-inclusive. If a method of installation or operation not specifically recommended by us is used, you must satisfy yourself that it is safe for you and for others. You should also ensure that the unit will not be damaged or be made unsafe by the methods that you choose.

The information, specifications, and illustrations in this manual are based on the information that was available at the time this material was written and can change at any time without notice.

Safety Alert Symbols



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.

This manual contains DANGERS, SAFETY INSTRUCTIONS, CAUTIONS, IMPORTANT NOTICES, and NOTES which must be followed to prevent the possibility of improper service, damage to the equipment, personal injury, or death. The following key words call the readers' attention to potential hazards.

Hazards are identified by the "Safety Alert Symbol" and followed by a signal word such as "DANGER", "WARNING", or "CAUTION".

DANGER

Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury. This signal word is limited to the most extreme situations.

WARNING

Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.

CAUTION

Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.

NOTICE























Indicates that equipment or property damage can result if instructions are not followed.

SAFETY INSTRUCTIONS

Safety instructions (or equivalent) signs indicate specific safety-related instructions or procedures.

Note: Contains additional information important to a procedure.

Safety Icon Nomenclature

	Read the manual
	Eye protection
	Foot protection
	Hand protection
	Hearing protection
	Inspect equipment
	Two person operation
	Warning decal alert
	Bending hazard (hydraulic hose)
	Crushing hazard
	Crushing hazard (hand)
	Do not weld
	Electrocution hazard
	Explosion hazard
	High-pressure fluid hazard
	Impact hazard (hydraulic hose)
	Pressurized fluid
	Projectile hazard (body)
	Protective guards
	Safety alert symbol
	Slipping hazard
	Tripping hazard

Safety Warnings

General Safety

WARNING



To avoid personal injury or death, carefully read and understand all instructions before attempting to assemble and/or operate the Post Driver. Do not operate or work on equipment unless you read and understand the instructions and warnings in this and all other applicable manuals. Contact Shaver Manufacturing Company if any of the instructions provided are unclear or not understood. Proper care is your responsibility. Always follow all State and Federal health and safety laws and/or local regulations.



To help prevent personal injury, protective equipment must be worn during Post Driver assembly, operation, and maintenance. Personal protective equipment should include, but not be limited to, safety glasses, hearing protection, protective gloves, and steel toe footwear.

Personal injury can result from slips or falls. DO NOT leave tools or parts lying around the work area, and clean up all spilled fluids immediately.

Hazard Avoidance

WARNING



Inspect this equipment before each use. Make sure all hardware is tight. Always replace worn or damaged parts before use.



To avoid personal injury or death, do not operate the Post Driver by yourself. Always have another person to control the machine or power source.

WARNING



Make sure all decals are securely attached to the Post Driver and are legible at all times. Always read and understand all decals before working on or operating the Post Driver.



Make sure all lock-pins and transport supports are secured in place before transporting or storing the Post Driver. While transporting, never ride on or permit others to ride on the Post Driver.



Improper operating procedures can create risk for the operator and bystanders. DO NOT use the Post Driver before making sure no one will be endangered.



To prevent personal injury or death, be aware of overhead electrical lines when operating the Post Driver. Electrocutation can occur even without direct contact with overhead power lines. Proceed cautiously around electrical lines and utility poles.



To prevent personal injury or death, always check for underground utilities, such as electrical wires, gas lines, and water pipes, before driving posts. Contact local utility companies for information on locating underground utilities.



To avoid serious injury or death, do not operate the Post Driver on steep slopes, as this can cause a roll over.



To avoid personal injury, always stand 45 degrees to the right of the post being driven while operating the Post Driver.

! WARNING



Potential pinch points. Keep hands clear of Post Driver while operating. Never place hand(s) on top of a post when inserting it into the Post Driver. Always close the safety arm before driving the post.



To avoid personal injury do not attempt to clean, adjust, or lubricate the Post Driver while it is in motion.



The rubber debris guard helps shield the operator from flying debris that may be generated during post driving. To avoid personal injury, make sure the rubber debris guard is securely attached to the Post Driver before driving posts.



To avoid personal injury or death, do not modify the Post Driver by welding, drilling, or grinding. Do not expose to extreme heat, such as from a torch.



The main carriage channel assembly is tall and heavy. To avoid tip over, resulting in serious injury or death, leave the overhead lifting device attached to the main carriage channel while assembling components.



To avoid serious injury or death, the safety arm must be installed after the Post Driver has been mounted on a machine, or the freestanding Post Driver has been secured to prevent tipping.

Hydraulic Hoses

! WARNING



Avoid damaging hydraulic hoses. Avoid sharp bends and kinks when routing hydraulic hoses. Using a bent or kinked hose will cause severe back-pressure. Sharp bends and kinks can internally damage the hose, leading to premature hose failure, resulting in personal injury.

! WARNING



Do not drop heavy objects on hoses. A sharp impact may cause internal damage to the hose. Applying pressure to a damaged hose may cause it to rupture, resulting in personal injury.



Mismatched couplings and hoses can cause the coupling to violently disconnect from the hose when placed under pressure; separating with sudden, extreme force which can result in property damage, personal injury, or death.

Replace a hose if any of the following conditions are present:

- End fittings that are damaged or leaking
- Outer coverings that are chafed or cut
- Wire shields that are exposed
- Outer coverings that are ballooning
- Flexible part of the hoses that are kinked
- End fittings that are displaced



Pressure can be trapped in a hydraulic system. Trapped pressure can cause sudden movement of an attachment. Use **c a u t i o n** when disconnecting hydraulic lines or fittings. High-pressure oil that is released can cause a hose to move violently while spraying oil.



Escaping high-pressure fluid can penetrate the skin, causing serious injury. Relieve pressure before unhooking hoses. Check/tighten all connections before activating hydraulics. Never use your hand to check for leaks.

Introduction

The Shaver Manufacturing Company would like to congratulate you on your purchase of the Shaver Hydraulic Post Driver. You have selected the best Post Driver in its class. The clean design and uncomplicated working principle have made Shaver the largest selling Post Driver in the country.

The Shaver HD-8-S & HD-10-S (manual tilt adjustment) and HD-8-H-S, HD-10-H-S, & HD-12-H-S (hydraulic tilt adjustment) Hydraulic Post Drivers are a durable piece of equipment that, with regular maintenance, will provide many years of service.

This manual provides information regarding assembly, operation, and maintenance. It is important to read and become familiar with this manual before assembling or operating the Shaver Hydraulic Post Driver.

NOTE: For other valuable information on farm equipment operation and safety, refer to the following resources.

- **Farm Equipment Manufacturers Association (FEMA)**
<http://www.farmequip.org/home>
- **National Ag Safety Database**
<http://www.cdc.gov/nasd/>

Product Information



Record the Shaver product information here. The model number and serial number are found on the metal tag attached to the drive ram (see arrow above).

Model Number _____

Serial Number _____

Date Purchased _____

Dealer Name _____


Specifications

DESCRIPTION	HD-8-S & HD-8-H-S	HD-10-S & HD-10-H-S	HD-12-H-S
Approximate Height ¹	88 in (223.5 cm) collapsed 133 in (337.8 cm) extended	100 in (254 cm) collapsed 148 in (376 cm) extended	100 in (254 cm) collapsed 148 in (376 cm) extended
Approximate Width ²	30 in (76.2 cm)	44 in (111.8 cm)	44 in (111.8 cm)
Approximate Depth ²	28 in (71.1 cm)	33 in (88.8 cm)	38 in (96.5 cm)
Shipping Weight	694 lbs (315 kg) manual base 714 lbs (324 kg) hydraulic base	694 lbs (315 kg) manual base 714 lbs (324 kg) hydraulic base	975 lbs (442 kg)
Effective Weight of Driving Ram	360 lbs (163.3 kg)	725 lbs (329 kg) Spring Powered	1,100 lbs (499 kg)
Impact (at full stroke)	30,000 lbs (13,607.8 kg)	71,500 lbs (32,432 kg)	100,000 lbs (45,359 kg)
Tilt Front/Back	15°/15°	15°/15°	20°/20°
Tilt Side/Side	15°/15°	15°/15°	25°/25°
Guide Blocks or Rollers	4 (2 per side)	4 (2 per side)	6 (3 per side)
Mounting Options	Tractor (rear/front) and skid steer Three-Point Hitch Category I and II	Tractor (rear/front) and skid steer Three-Point Hitch Category II and III	Tractor (rear) and skid steer Category II and III
Hydraulic Requirements	3 - 4 GPM at 1500 PSI (11.3-15.1 LPM at 10,342 kPa)	12 GPM at 1500 PSI (45 LPM at 10,342 kPa)	15 GPM at 2000 PSI (45 LPM at 13,790 kPa)
Post Size Maximums	Width 7-1/8 in (18.1 cm) Length 10 ft (3.0 m)	Width 8-3/4 in (22.2 cm) Length 10 ft (3.0 m)	Width 10-7/8 in (27.6 cm) Length 10 ft (3.0 m)

¹ Driving ram and main carriage channel. Overall height will vary, depending on mounting position and tractor.

² With storage legs attached to three-point hitch weldment.

Safety Sign Locations



Driver Safety Signs and Informational Labels

Item	Part Number	Description
1	MS-162	Decal, Danger Instructions
2	MS-165	Decal, Danger Safety Arm Attachment
3	MS-163	Decal, Warning Pinch Point
4	MS-181	Decal, Warning Pinch Point
5	MS-171	Decal, Warning High Pressure Hydraulics
6	MS-105	Decal, Important Valve Instructions
7	MS-166	Decal, Important Leave Arm Open
8	SM-0011-ST	Tag, Caution Springs
9	MS-180	Decal, Cylinder Nut

Safety Signs

1. MS-162 – Decal, Danger Instructions



2. MS-165 – Decal, Danger Safety Arm Attachment



3. MS-163 – Decal, Warning Pinch Point




4. MS-181 – Decal, Warning Pinch Point



5. MS-171 – Warning High Pressure Hydraulics Decal



6. MS-105 – Decal, Important Valve Instructions




7. MS-166 – Decal, Important Leave Arm Open



8. SM-0011-ST –Tag, Caution Springs



9. MS-180 – Decal, Cylinder Nut



Assembly Procedure

Unpacking



Due to the size and weight of the Post Driver, two people are required for the assembly procedures.



The Post Driver is shipped in several sections: the Driving Ram Assembly, Base Plate Assembly, Hose and Valve Carton, Safety Arm Carton, and with the Hydraulic Post Driver (HD-8-H-S, HD-10-H-S, & HD-12-H-S) the Tilt Cylinder Carton.

⚠ WARNING



Before starting the unpacking procedure, make sure the overhead lifting device or material handling device (forklift) has adequate lifting capacity. Follow all safety recommendations when unpacking the Post Driver. Some components are heavy and can cause serious injury or death if not adequately supported during removal and assembly.


NOTE: For ease of assembly, unload the Post Driver components in the area where they will be assembled. Choose a large, hard surface area that can safely support the weight of the assembled Post Driver and is accessible by the machine it will be mounted on.

Assembly

NOTE: Refer to the Service Parts section of this manual for an illustration and description of all the parts.

The Main Carriage Channel has provisions for mounting the Base Plate (Manual or Hydraulic) in three positions.

- The **Middle** Position (most common) - three-point hitch or tractor front mount (midsized tractors).
- The **Upper** Position - tractor front mount (larger tractors).
- The **Lower** Position - for driving 10 ft. (3.0 m) tall posts only - three-point hitch or front tractor mount (smaller tractors).



Driver and Base Plate on 3-point mount shown in **Middle** Position.


The Post Driver assembly procedure consists of the following subsections:

1. Main Carriage Channel
2. Storage Legs
3. Base Plate
4. Hydraulic Valve
5. Safety Stop Adjustment
6. Rubber Debris Guard
7. Safety Arm
8. Manual Storage Tube

Mounting Instructions


Front-Mounted

1. Attach the Mounting Bracket(s) to the front of the tractor with the bolts provided. If no bolts are provided, use the bolts in the frame. Please refer to the individual instructions supplied with the tractor mounting kit.



NOTE: Manual base plate installation is shown. Installation of Hydraulic base plate is similar.

2. Remove the carriage bolts, washers, and nuts from Manual base plate. Also remove the Base Plate Pins and the cotter pins at each end. Save the hardware and pins for the next step.



3. Install manual base plate on front mount adapter as shown. Install carriage bolts, washers, lock washers, and nuts removed in Step 1. Center the base plate on the three-point hitch and tighten the hardware securely.

Main Carriage Channel

4. Use a suitable overhead lifting device (arrow as shown) to raise (stand up) Main Carriage Channel. Position the Driver in front of the Base Plate as shown below.




⚠ WARNING




The Main Carriage Channel assembly is tall and heavy. To avoid tip over, resulting in serious injury or death, leave the overhead lifting device attached to the Main Carriage Channel while assembling components.

- Align the bushings in the Driver with the bushings in the Base Plate (see arrows below). Install Pins and secure with the supplied cotter pins.



Front mounting of driver HD-10 shown.

Mounting Instructions




Rear-Mounted (3-Point Hitch)

- Place three-point hitch weldment upside down on the floor. Install storage leg brackets with storage legs installed, over the cross tube, as shown. Tighten two leg bracket bolts to secure the brackets to the cross tube.
- Set storage leg height 'X' measured from three-point hitch weldment mounting angles to the storage leg base plate, as shown. Tighten the storage leg lock bolts.
 - For **UPPER** Base Plate mounting position set 'X' at **36"** (91.44 cm).
 - For **MIDDLE** Base Plate mounting position set 'X' at **45"** (114.3 cm).
 - There is no useable dimension 'X' for storage legs when diver is in the **LOWER** Base Plate mounting position
- Turn over three-point hitch weldment and set it on storage leg base plates.

Self-Contained Mounting Package

- Remove the plugs from the hydraulic reservoir, pump, and motor.

- Place Universal Mounting Bracket (item 1) on the floor. Install the Reservoir Bracket (item 3) on the outside of the mounting angles on the Universal Mounting Bracket with two (2) each 1/2" bolt, lock washer and nut (items 9, 10, & 11). Attach the Pump/Motor/Reservoir (item 2) by lining up the slots in the Pump/Motor/Reservoir with slots in the Universal Mounting Bracket and the Reservoir Bracket, then secure four (4) each 3/8" bolt & lock nut and eight (8) flat washer (see below).




OH-200 - Self-Contained Mounting Package Assembly.

Item	Qty.	Part No.	DESCRIPTION
1	1	MBS-77-20	Bracket Assy., Universal Mtg.
2	1	OH-101-1	Pump/Motor Kit, Complete
3	1	OH-101-2B	Frame Weldment, Reservoir Bracket
4	1	SM-0252-R	Hose Assy., Hyd. 3/4" x 48" 3/4" MNPT
5	1	300340	Bushing, Reducer 1"NPT x 3/4" NPT
6	3	SM-1022-P	Hose Assy., Hyd. 1/2" x 54" 1/2" MNPT
7	1	CT-832-MC	Coupler, 1/2" Male Flat Face
8	1	CT-832-FC	Coupler, 1/2" Female Flat Face
9	2	300326	Screw, Cap 1/2 -13 x 3 Hew Head Gr5 Zn
10	2	300101	Washer, Lock 1/2 Zn
11	2	300102	Nut, Hex 1/2-13 Zn
12	4	300189	Bolt, Tap 3/8-16 x 1" Gr5 Zn
13	8	300178	Washer, Flat 3/8 Std. Zn
14	4	300181	Nut, Lock 3/8-16 Zn

IMPORTANT NOTICE

The following hydraulic fittings and hoses require a paste type sealer. Do not use a tape-type sealer, such as Teflon Tape, as this can contaminate the system and voids the valve warranty.

- Install hoses as follows (see above). Screw in the Bushing Reducer (item 5) into the open port on the top of the tank next to the breather cap, then screw in one end of the 3/4" x 48" hose (item 4) into the Bushing Reducer. The other end of the hose goes to the 90° fitting in the 'T' port on the hydraulic control valve.
- A 1/2" x 54" hose (item 6) connects to the 45° fitting in the hydraulic pump and the other end attaches to the 90° fitting in the 'P' pressure port on the top of the hydraulic control valve.
- The other two (2) 1/2" x 54" hoses (item 6) connect to the 90° fittings in the hydraulic motor and the other ends attach to the Quick Couplers (item 7 & 8). The Female Coupler (item 8) connects to the hose going to the check valve on the hydraulic motor. The Male Coupler attaches to the other hose connected to the hydraulic motor.
- The self-Contained Mounting Package should look similar to below when completed.




OH-200 - Self-Contained Mounting Package completely assembled.


Base Plate (Hydraulic or Manual)

NOTE: Hydraulic base plate installation is shown. Installation of manual base plate is similar.

1. Remove the carriage bolts, washers, and nuts from hydraulic base plate. Save the hardware for reuse.



2. Install hydraulic base plate on three-point hitch weldment, as shown. Install carriage bolts, washers, lock washers, and nuts removed in Step 1. Center the base plate on the three-point hitch and tighten the hardware securely.
3. Install hydraulic cylinders on hydraulic base plate, along with scissor stop assembly as shown below. Secure with cotter pins (included).




NOTE: Side tilt cylinder (A) is secured with cylinder mounting pins (D). Forward tilt cylinder (B) and scissor stop assembly (C) are secured with cylinder mounting pin (E) and channel mounting pin (F). Install supplied cotter pins in both ends of all mounting pins.

! WARNING



The Main Carriage Channel Assembly is tall and heavy. To avoid tip over, resulting in serious injury or death, leave the overhead lifting device attached to the Main Carriage Channel while assembling components.



Proper lifting device (large arrow above) when attaching Driver to Base Plate.

Attaching the Driver to Base Plate.

- a. Position and align Driver with lower base plate pivot location (A above). Install the pin and secure with included cotter pins.
- b. Manually extend Forward Tilt Cylinder, align and install upper mounting pin (B above) and scissor stop safety lever (C above). Make sure scissor stop safety lever (C above) is installed on upper mounting pin (B above). Secure with included cotter pins.

NOTE: If using Manual Base Plate Assembly, first position and align Driver with lower base plate pivot location (**A below**), then install mounting pin. Adjust forward tilt crank and side tilt crank to align upper mounting pin holes (**B below**), then install upper mounting pin. Secure pins with included cotter pins.



Manual Base Plate Assembly.

Connection to Hydraulic Supply


The customer must supply suitable hydraulic quick disconnect fitting for connecting pressure supply hose. For return hose to the tractor or power supply hydraulics system, use the appropriate adaptor listed for your tractor in the **TRACTOR LISTING** spread sheet, see your dealer or distributor.

Hydraulic Valve & Hose Installation

IMPORTANT NOTICE

Hydraulic system fittings that require a thread sealant must be installed with a paste-type sealer only. Do not use a tape-type sealer, such as Teflon Tape, as this can contaminate the system and voids the valve warranty.

Single Lever Control Valve for Manual Base Plate




Manual Tilt Base Control Valve (see parts chart below).

Single Lever Control Valve for Manual Base Plate Parts List			
Item	Qty.	Part No.	Description
1	1	SM-002-VBP	Plate, Valve Bracket V-01,V02
2	1	V-01-SP	Valve – 1 Spool
3	1	SM-0234-P	Hose Assy., 1/2 x 120
4	1	SM-025-R	Hose Assy., 3/4 x 120
5	1	SM-0252-R	Hose Assy., 3/4 x 48
6	1	F-6902-10-12	Adapter, 45° SAE#10MORB-3/4FNPT
7	1	SC-2550-C	Adapter, 90° SAE#10MORB-1/2FNPS
8	1	SC-50-H52	Adapter, 90° SAE#12MORB-3/4FNPT

1. Remove the plugs from the hydraulic control valve.
2. Install the hydraulic valve (item 2) on Valve Bracket (item 2) using two (2) 5/16-18 x 3” valve mounting bolts, washers, and nuts. **NOTE: Do not over-tighten the hardware, which can warp valve body.**


3. Attach the valve and mounting bracket to the Driver Base Plate using base plate mounting hardware in the right rear side of the plate.
4. Screw in hydraulic fittings (items 6, 7, & 8) as shown above. The 45° SAE#10MORB-3/4FNPT Adapter (Item 6) goes into ‘A’ working port on top of the valve. The 90° SAE#10MORB-1/2FNPS Adapter (item 7) goes into the ‘P’ pressure port on top of the valve. The 90° SAE#12MORB-3/4FNPT Adapter (item 8) goes into the ‘T’ side return port on the valve.



Manual Tilt Base Control Valve hoses (see parts chart to left).

5. Attach the hoses as follows (see above). Screw in one end of the 3/4 x 48” hose (item 5) to the 45° fitting in the ‘A’ working port on top of the valve and the other end to the port on the driver cylinder using paste-type thread sealant on the fittings. The 1/2 x 120 hose (item 3) connects to the 90° fitting in the ‘P’ pressure port on the top of the valve and the other end is hooked up to the pressure hydraulic line from tractor using paste-type thread sealant on the fittings. The 3/4” x 120 Return line hose is screwed into the 90° fitting from the ‘T’ port of the valve using paste-type thread sealant on the fitting.
6. For the other end of the return hose use the appropriate adaptor listed for you tractor in

the **TRACTOR LISTING** spread sheet (see below) using paste-type thread sealant on the fitting.



Return line and adaptor (SM-10-R Adaptor is shown).


IMPORTANT: For the Driver to function properly the return line must be connected directly to the hydraulic reservoir of the tractor or skid loader.

IMPORTANT NOTICE

The hydraulic valve and cylinder(s) can be damaged by contamination (dirt and debris) from the oil in the tractor or power source. Ensure the oil is clean and properly filtered before connecting the Post Driver to a hydraulic power source. Failure to follow oil cleanliness standards voids the Shaver Post Driver warranty.

Triple Lever Control Valve for Hydraulic Base Plate


1. Remove the plugs from the hydraulic control valve.



Hydraulic Tilt Base Control Valve fitting.


Triple Lever Control Valve for Hydraulic Base Plate Parts List			
Item	Qty.	Part No.	Description
1	1	SM-003-VBP	Plate, Valve Bracket V-03
2	1	V-03-SP	Valve - 3 Spool
3	1	SM-0234-P	Hose Assy., 1/2 x 120
4	1	SM-025-R	Hose Assy., 3/4 x 120
5	1	SM-0252-R	Hose Assy., 3/4 x 48
6	4	SM-02111-P	Hose Assy., 1/4 x 26
7	1	F-6902-10-12	Adapter, 45° SAE#10MORB-3/4FNPT
8	1	SC-2550-C	Adapter, 90° SAE#10MORB-1/2FNPS
9	1	SC-50-H52	Adapter, 90° SAE#12MORB-3/4FNPT
10	2	P-910181	Adapter, 90° SAE#10MORB-1/4FNPT
11	2	F-6410-10-06	Adapter, Str. SAE#10MORB-#6FORB
12	2	F-6902R-6-4-.03	Adapter, 45° SAE#6MORB-1/4FNPS

2. Install the hydraulic valve (item 2) on Valve Bracket (item 2) using three (3) 5/16-18 x 3" valve mounting bolts, washers, and nuts. **NOTE: Do not over-tighten the hardware, which can warp valve body.**
3. Attach the valve and mounting bracket to the Driver Base Plate using base plate mounting hardware in the right rear side of the plate.
4. Screw in hydraulic fittings (items 7, 8, & 9) as shown above. The 45° SAE#10MORB-3/4FNPT Adapter (Item 7) goes into 'A3' working port on top of the valve. The 90° SAE#10MORB-1/2FNPS Adapter (item 8) goes into the 'P' pressure port on top of the valve. The 90° SAE#12MORB-3/4FNPT Adapter (item 9) goes into the 'T' side return port on the valve.
5. Then screw in hydraulic fittings for the Tilt Cylinders (items 10, 11, & 12) as shown above. Two (2) 90° SAE#10MORB-1/4FNPT Adapter (Item 10) go into 'A1' & 'B1' working ports on top of the valve. Two (2) straight SAE#10MORB-#6FORB Adapters (item 11) go into the 'A2' & 'B2' working ports on top of the valve. Then two (2) 90° SAE#6MORB-1/4FNPS Adapters (item 12) go into the straight adapters in 'A2' & 'B2' working ports on top of the valve.



Driver hydraulic hoses.

- Attach the hoses as follows (see above). Screw in one end of the 3/4 x 48" hose (item 5) into the port on the driver cylinder using paste-type thread sealant on the fitting. The four (4) 1/4 x 26" hoses (items 6a, b, c, & d) connect to the four (4) ports on the tilt cylinders using paste-type thread sealant on the fittings.



Hydraulic Tilt Base Control Valve hoses.

Hydraulic Hose Chart		
Item	Valve Port	Location
3	P	Pressure Hose
4	T	Return Hose
5	A3	Driver Cylinder
6a	A1	Side Tilt Cylinder Rod End
6b	B1	Side Tilt Cylinder Base End
6c	A2	Forward Tilt Cylinder Rod End
6d	B2	Forward Tilt Cylinder Base End

- Attach the other ends of the hoses as follows (see above). Screw in one end of the

3/4 x 48" hose (item 5) to the 45° fitting in the 'A' working port on top of the valve using paste-type thread sealant on the fittings. The 1/2 x 120 hose (item 3) connects to the 90° fitting in the 'P' pressure port on the top of the valve using paste-type thread sealant on the fittings and the other end is hooked up to the pressure hydraulic line from tractor. The 3/4" x 120 hose is screwed into the 90° fitting from the 'T' port of the valve using paste-type thread sealant on the fittings.


- Attach the tilt cylinder hoses as follows (see chart & illustration on the left). Attach the other end of the hose connected to the rod end of the side tilt cylinder (item 6a) to the 90° fitting from the 'A1' port of the valve using paste-type thread sealant on the fitting. Then attach the other end of the hose connected to the base end of the side tilt cylinder (item 6b) to the 90° fitting from the 'B1' port of the valve using paste-type thread sealant on the fitting. Do the same with the forward tilt cylinder hoses. The rod end hose (item 6c) goes to the 45° fitting from the 'A2' port of the valve and the base end hose (item 6d) goes to the 45° fitting from the 'B2' port of the valve.

IMPORTANT NOTICE

If the tilt cylinder hoses are attached differently than shown, the control of the drive ram will not be as described in this manual.

NOTE: Make sure all hose fittings are tight.


- For the other end of the return hose use the appropriate adaptor listed for you tractor in the **TRACTOR LISTING** spread sheet.



Return line and adaptor (SM-10-R Adaptor is shown).

IMPORTANT: For the Driver to function properly the return line must be connected directly to the hydraulic reservoir of the tractor or skid steer.


Note: Tilt Cylinder Levers on the valve can be repositioned from their normal vertical to a horizontal position. To reposition the levers, loosen the jam nut on the lever and unscrewing the lever. Move the lever to the horizontal location and screw the lever in and then tighten the jam nut.



Tilt Levers alternate position on Control Valve (arrows above).

Rubber Debris Guard

1. Locate rubber debris guard and bag containing hardware and caution tag.



Rubber Debris Guard mounting (HD-10 shown).

2. Attach Rubber Guard and Caution Tag on drive ram, with guard mounting hardware, three (3) 1/4-20 x 1" Carriage Bolts, Lock Washers, and Nuts, as shown above.

NOTE: To avoid damage to the Rubber Debris Guard, do not over-tighten the mounting hardware.


Safety Arm Assembly

! WARNING




To avoid serious injury or death, the safety arm must be installed after the Post Driver has been mounted on a machine, or the freestanding Post Driver has been secured to prevent tipping.

1. Locate safety arm assembly parts and hardware.




Safety Arm Mounting holes (HD-10 with manual base plate shown).

2. Locate the set of two (2) mounting holes in the Stabilizer Channel to be used to attach the Safety Arm.



Safety Arm Mounting Bracket in Middle Position (HD-10 with Manual Base Plate shown).

- Attach safety arm frame to inside of stabilizer channel with two (2) 3/4-10 x 2" bolts and self-locking nuts, as shown above. Tighten nuts securely.



Safety Swing Arm & Roller Holder assembly


- Assemble two Rollers onto Roller Holder and secure with two Roll Pins, as shown above.
- Apply a light film of good quality grease to the pivot shaft and attach Roller Holder to Swing Handle Arm with Nylon Lock Nut as shown above. Tighten Nut until seated and then loosen 1/4 to 1/2 turn.

NOTE: Roller Holder must swivel freely on Swing Handle Arm.

⚠ WARNING



To avoid serious injury or death, the safety arm must be installed after the Post Driver has been mounted on a machine, or the freestanding Post Driver has been secured to prevent tipping.



Safety Arm Mounting (HD-10 shown)

- Install the Swing Arm Assembly.
 - Apply a light film of good quality grease to the pivot shaft on Swing Arm Assembly.
 - Slide the pivot shaft into the tube on the Safety Arm Mounting Bracket and secure with cotter pin as shown above.
 - Slide the open spring eye over the Mounting Bracket anchor rod and secure with a flat washer & cotter pin.
 - Slide the other end of the spring eye over the anchor rod on the Swing Arm Assembly and secure with a flat washer & cotter pin.
- Verify the swing arm handle opens against safety arm frame stop bracket and closes against back wall of drive ram beam.



Drive Ram and Safety Arm with fence post.


NOTE: When driving a fence post, the swing arm rollers must contact and hold the fence post in position, as shown above.

Document Storage Tube



Manual Storage Tube & mounting rivets.

1. If desired, locate the document storage tube in a convenient location on the Post Driver. The photo below shows the tube mounted on the base plate, but other locations are acceptable.




Manual Storage Tube mounted on Base Plate.

2. Mark the location of the two mounting holes using the storage tube as a guide (arrows above).
3. Drill two 3/16" holes.
4. Attach the storage tube with the two pop rivets supplied inside the tube.

Attachment and Option Assembly

Concrete Breaker Accessory


1. Position the Concrete Breaker to the bottom of the Driving Ram as shown below, without the mounting hardware installed. Using Concrete Breaker as a guide mark and drill mounting holes (9/16" diameter for CB-1/HD-8 and 11/16" diameter for CB-2/HD-10 & CB-3/HD-12).



Concrete Breaker CB-2 for HD-10 shown mounted.

2. Secure with supplied mounting hardware as shown above.

Steel Post Holder Accessory



Steel Post Holders for HD-8 shown. Steel T-Post Holder on left and Steel Square Post Holder on right.

Post Driver Operation

Operational Safety Tips


1. Follow all safety information contained in this manual and refer to safety decals located on the Post Driver.
2. Personal safety equipment must be worn at all times during operation, i.e. safety glasses, steel toe shoes, hearing protection, etc.
3. Always stand 45 degrees to the right of the post while the Post Driver is in operation.
4. **Do not** remove any of the Post Driver safety equipment or safety labels.
5. All Post Driver safety equipment must be inspected, maintained, kept in working order, and used during Post Driver operation.
6. **Do not** place your hand(s) on top of the post when placing the post in the Post Driver or while the Post Driver is operating.
7. Leave the Safety Arm Attachment open when not holding a post, except when transporting the Post Driver.
8. **Do not** remove the hydraulic control valve safety lever stop.
9. Never use the maximum force of the Post Driver until the post being driven is started into the ground and is straight.
10. Use caution when driving small diameter wood or steel posts. Maximum driving impact is not necessary.
11. Always be aware of the environment in which you are operating the Post Driver.
12. **Do not** operate the Post Driver on steep slopes, as this could cause a roll over.
13. Always check for underground utilities, i.e. wires, gas lines, waterlines, etc. Call your local utility companies for underground utility locations.
14. Use caution where large rocks or other objects could be hidden underground and not visible to the operator. The post could splinter and cause injury to the operator. If the post fails to drive into the ground after two or three strikes, move to another location.
15. **Do not** operate the Post Driver with the machine or power source unattended. The Post Driver requires two people for proper operation - one operating the Post Driver and one on the tractor.
16. Always engage the Road Lock Pin in the Drive Ram upper hole before transporting.

Operating Instructions

3-Point Hitch Mounting

1. With the Post Driver positioned on a hard level surface, move the tractor or other power supply toward the Post Driver until the three-point hitch lines up.
2. Attach two lower, three-point hitch lift arms to Post Driver three-point hitch weldment hitch pins ('A' below). Secure with lock pins (operator supplied).
3. Attach the three-point top link to removable pin ('B' below) and secure with cotter pin.

NOTE: Adjust the length of the machine's top link, as required, to correctly attach the Post Drivers 3-Point Mounting Bracket.




Three-Point Hitch Assembly, Top Link Pin, & Cotter Pin.

NOTE: The **HD-8** Post Driver will fit tractors with Category I or Category II three-point hitches. Use bushings on hitch pins, if required, to correctly install lift arms.

NOTE: The **HD-10** & **HD-12** Post Drivers will fit tractors with Category II or Category III three-point hitches. Use bushings (Owner/operator supplied) on the hitch pins, if required, to correctly install the lift arms.

4. Attach hydraulic pressure supply hose (small diameter) to the tractor pressure supply port. Attach hydraulic return hose (larger diameter) to hydraulic fill port/tube.



Control Valve, Hydraulic Pressure Hose, and Hydraulic Return Hose.

NOTE: The operator is responsible for installing quick-disconnect fittings (or other suitable fittings) on the Post Driver hoses. Make sure the fittings are compatible with the tractor hydraulic fittings.

5. When traveling always install the road lock pin (arrow below) in the "transport" position as shown below. The Post Driver can now be moved to the work site.




Drive Ram & Road Lock Pin in transport position.

Operating Instructions

Self-Contained Mounting

1. With the Post Driver positioned on a hard level surface, move the skid loader or other quick attach bracket equipped unit toward the Post Driver until the plates line up. Lift the Driver off the ground and lock with the skid loader locking arms.



Self-Contained mounting and hydraulic hook-up to skid loader.


2. Locate the hose connected to the check valve (A) attached to the hydraulic motor. This is the pressure hose. Connect the quick coupler to the skid loaders hydraulic pressure source (B). The other quick coupler is connected to the return line (C). See above.

Preparing to Drive a Post

IMPORTANT NOTICE

If operating on uneven ground, make sure the stabilizer leg firmly contacts the ground at each new fence post location. Failure to do so can cause damage to the Post Driver components.


1. Position the tractor or power source in place to drive the first fence post.
2. Set the brakes on the tractor or power supply. If the machine is equipped with an automatic transmission, the transmission must be in PARK.



Drive Ram, Stabilizer, & Storage Legs.

IMPORTANT: When operating the Ram ('A' above) to drive in posts, the Stabilizer ('B' above) must be positioned on the ground. The Storage Legs ('C' above) are not used during operation of the Driver and should be in the raised position, off of the ground when driving posts; they are for storage of the Driver only.

3. Remove Road Lock Pin ('D' below) and lower Driver until the Stabilizer ('B' below) rests on ground. Store Road Lock Pin in a secure location.



Drive Ram, Stabilizer, & Road Lock Pin.

Driving a Post

1. Lubricate four (HD-8/HD-10) or six (HD-12) guide blocks with oil before each daily use and, if necessary, between post installations.

IMPORTANT NOTICE

Do not use grease on the guide blocks or in the main carriage channel. Grease will retain abrasive material, which will result in premature wear.




Guide Block/Roller locations (arrows) on Driver (HD-10 shown with transparent Main Carriage).

⚠ WARNING



To avoid personal injury or death, do not operate the Post Driver by yourself. Always have another person to control the machine or power source.

NOTE: For operation of valve control levers refer to the illustration below.




Valve control lever operation.

IMPORTANT NOTICE


If the tilt cylinder hoses are attached differently than shown, the control of the drive ram will not be as described in this manual.

2. Pull up Safety Latch and pull back Main Hydraulic Control Lever to raise Drive Ram.



Drive Ram, Hydraulic Control Valve Lever, & Safety Lever.

3. Pull up Safety Latch and push Main Hydraulic Control Lever to lower Drive Ram.



Drive Ram, Hydraulic Control Valve Lever, & Safety Lever.

IMPORTANT NOTICE

AT THE BEGINNING OF EACH DAY, USE THE MAIN HYDRAULIC CONTROL LEVER TO CYCLE THE DRIVE RAM UP AND DOWN 10 TO 15 TIMES, WITHOUT IMPACT WITH A POST OR THE GROUND, TO "SEASON" THE DRIVE RAM RETURN SPRINGS. FAILURE TO FOLLOW THIS RECOMMENDATION CAN CAUSE DAMAGE TO THE SPRINGS.


NOTE: THE TRACTOR OR OTHER POWER SOURCE MUST BE CAPABLE OF MAINTAINING ADEQUATE HYDRAULIC PRESSURE (ENGINE RPM) TO SMOOTHLY OPERATE (CYCLE) THE POST DRIVER.

⚠️ WARNING




Potential Pinch Points. Keep hands clear of Post Driver while operating. Never place hand(s) on top of a post when inserting it into the Post Driver. Always close the safety arm when driving the post.

4. With the drive ram in the raised position and the safety arm swung out of the way, place a fence post in the I-beam, under the drive ram hammer plate.




Positioning post in driver.

NOTE: There should be a 1" to 2" gap between the top of the fence post and the bottom of the drive ram hammer plate. Never drive a fence post without the guard in place.



Post to hammer plate gap shown with a transparent Debris Guard.

5. Close safety arm frame to secure the post (the adjustable roller assembly keeps tension on the post while it is being driven).



Safety Arm closed onto post.

6. **Do not** stand in front of the drive ram while operating the Post Driver. Stand at a 45 degree angle to the side of the Post

- To drive the fence post straight, adjust the main carriage channel side-to-side and fore-and-aft using manual cranks (manual base plate) or second and third hydraulic control valve levers (hydraulic base plate).



Tilt top of Drive Ram away from operator pull first lever toward operator.



Tilt top of Drive Ram toward operator push first lever away from operator.




Tilt top of Drive Ram away from tractor/skid loader pull middle lever toward operator.




Tilt top of Drive Ram toward tractor/skid loader push middle lever away from operator.

8. Pull up Safety Latch and pull back Main Hydraulic Control Lever to raise Drive Ram.



Drive Ram, Hydraulic Control Valve Lever, & Safety Lever.

9. Hold up Safety Latch and push Main Hydraulic Control Lever to release the Drive Ram and create impact with post. Continue this process, as needed, to drive the post to the desired depth.



Drive Ram, Hydraulic Control Valve Lever, & Safety Lever.

IMPORTANT NOTICE


Posts will drive into the ground much straighter using shorter strokes. Use caution when driving small diameter wood and steel posts. Maximum impact is not necessary with these smaller diameter posts and can cause damage (splintering or breakage) of posts.

NOTE: If the post stops going down or is crooked after a few impacts, stop and move the post to a different location. Conditions such as thick sod, rocks, or tree roots can cause splintered or broken posts.

10. Once a post is driven to the desired depth the drive ram contacts the ground, release the hydraulic control lever.
11. Open safety arm frame.
12. Raise the Post Driver and move to the next location to begin driving a new post.
13. If traveling more than 100 feet, install road lock pin in upper "transport" position. The Post Driver can now be moved to the next work site or the storage location.


Dismounting Post Driver

1. Install road lock pin in upper "storage" position (lower hole is not used). The Post Driver should be stored on a hard level surface.



Road Lock Pin location (arrow).

2. Raise or lower the storage legs (small arrows) to allow drive ram I-beam (large arrow) full contact with the ground. Make sure the Post Driver is stable.



Drive Ram and Storage Legs.

NOTE: On units without storage legs, store the unit against a post driven into the ground. Position the unit with the driving ram next to the post and secure with a chain wrapped securely around the post and Post Driver.

⚠ WARNING



On hydraulic tilt Post Drivers, to prevent the forward tilt cylinder from drifting, tighten the bolt and nut on the cylinder scissor stop. Failure to tighten this bolt and nut could allow the dismantled Post Driver to fall over, causing serious injury or even death.


3. On hydraulic tilt Post Drivers, tighten the nut on cylinder Scissor Stop bolt (see arrow below) to prevent the cylinder from drifting and causing an unstable condition with the Post Driver.



Cylinder Scissor Stop Bolt.

NOTE: Failure to tighten this bolt could allow the Post Driver to fall over, causing serious injury or even death.

4. Make sure all pressure is released (zero pressure) from the Post Driver hydraulic system. Disconnect hydraulic pressure supply hose (A) from the tractor or skid loader. Disconnect hydraulic return hose (B) from the tractor or skid loader, see below.



Hydraulic Pressure Supply Hose (A), Hydraulic Return Hose (B), Top Link Pin (C), and Lower Lift Arms (D).

5. For 3-Point Hitch remove top link pin (C) from weldment and disconnect top link. Then disconnect the two tractor lower lift arms from the lower hitch pins (D) to separate the tractor three-point hitch from the Post Driver, see above.
6. Carefully move the tractor or power source away from the Post Driver.

Service Procedures



To avoid personal injury or death, carefully read and understand all instructions before attempting to assemble and/or operate the Post Driver. Do not operate or work on equipment unless you read and understand the instructions and warnings in this and all other applicable manuals. Contact Shaver Manufacturing Company if any of the instructions provided are unclear or not understood. Proper care is your responsibility. Always follow all State and Federal health and safety laws and/or local regulations.



To help prevent personal injury, protective equipment must be worn during Post Driver assembly, operation, and maintenance. Personal protective equipment should include, but not be limited to, safety glasses, hearing protection, protective gloves, and steel toe footwear.



Before making any adjustments on the Post Driver, ensure that all hydraulic levers are in the neutral position. Always shut off the machine, set parking brake, and remove key before performing any service.



Personal injury can result from slips or falls. DO NOT leave tools or parts lying around the work area, and clean up all spilled fluids immediately.

NOTE: Disassembly, assembly, and/or associated repairs must be performed with the main carriage channel and drives ram in a horizontal position, such as on a suitable pallet, or heavy-duty support stands.

Refer to Dismounting Post Driver from Machine/Power Source section for steps to remove Post Driver from a tractor or other power source.

Dismounting Post Driver from Base Plate

1. Secure the Post Driver upright to an appropriate overhead lifting device to prevent tipping (large arrow below).



Proper lifting device (large arrow above) when detaching Driver from Base Plate.


2. Disconnect drive cylinder to valve hose and drain fluid into a suitable container.
3. On Hydraulic Base Plate tighten Cylinder Stop Bolt and nut ('B' above).
4. Remove cotter pins and two (2) Base Plate Pins ('A' above) that connect the Base Plate to the Post Driver (applies to manual or hydraulic models).

NOTE: If necessary, lubricate channel mounting pins with penetrating oil to assist pin removal.

5. The upright assembly is heavy. Use an appropriate lifting device to position the Post Driver assembly horizontally, on suitable stands, pallet, or blocks on the ground.

Post Driver Disassembly

1. Remove Road Lock Pin and slide the Main Carriage Channel up as far as possible, to relieve tension on the Springs.
2. For HD-8/HD-10 Drivers connect retaining strap (A) to both Upper Spring eyes (B), with the strap positioned around the top of the Drive Ram Lift Yoke Bar (C) as shown below.



3. For HD-8/HD-10 use retaining strap to pull Springs up and off Upper Spring Bracket. Carefully loosen the retaining strap to release tension from the Springs.
4. For HD-12 carefully loosen and remove two upper return spring retaining bolts. **NOTE:** There can be tension remaining on spring. As the bolt is removed, the spring will quickly retract (compress) away from upper spring bracket.
5. Remove the retaining strap (HD-8/HD-10) and remove the Upper Spring Bracket (HD-10/HD-12).
6. Remove the Upper Cylinder Rod Self-Locking Nut ('D' above) and lock washer from the Drive Cylinder Piston. **NOTE:** Do

not reuse self-locking nut. Replace with a new self-locking nut.

7. For HD-8/HD-10 remove the two (2) self-locking nuts from Driver Cylinder and Lower Spring Bracket.
8. For HD-12 remove two lower spring bracket bolts, lock washers, and sleeves.
9. Slide the main carriage channel downward.
10. Remove the springs from the bottom of the Post Driver between the Drive Ram and the Main Carriage Channel.
11. Remove the Drive Cylinder by sliding it out the top of the Drive Ram Assembly.

NOTE: If Guide Blocks/Rollers need to be inspected and/or replaced continue with the next few steps, otherwise skip to the Seal and/or Spring replacement instructions.

12. Remove the Road Lock Bracket from the Main Carriage Channel.

CAUTION: Main Carriage Channel is heavy (HD-8 100+lbs., HD-10 120+lbs., & HD-12 210+lbs.), so get assistance and/or use an overhead lifting device to support it during removal.


13. Remove the Main Carriage Channel by sliding it out of the top of the Driving Ram.
 - Drive Ram I-beam.
 - Contact points on Guide Blocks/Rollers.
 - Main Carriage Channel.
 - Road Lock Bracket, Rubber Bumpers, and hardware.
 - Springs, and Upper and Lower Spring Mounting Brackets.

Seal Replacement

NOTE: Follow the disassembly instructions for the Post Driver until the Cylinder is out of Driving Ram.


1. Unscrew the Cylinder Cap and remove the Cap and Piston Rod.

IMPORTANT: PLEASE TAKE CARE DURING REMOVAL OF PISTON ROD TO PREVENT SCORING IT, TO AVOID OIL LEAKAGE.



Driver Cylinder disassembly.

2. Remove the Piston Guide Nut and Piston Guide (SM-02610) from the lower end of Piston Rod. Slide the Cylinder Cap down and off the Piston Rod. **DO NOT** slide the Cylinder Cap up and off the Piston Rod as the upper threads will score the inside of the Cylinder Cap.
3. Use a screwdriver or knife to remove the old Seal (see below).



4. Clean the seal groove in Cylinder Cap.
5. Squeeze the new Seal together and place one end of it into the cavity of the Cap. Force the Seal down and it will snap into place. This is easier to do if the Seal has been softened by placing it in hot (120°F) water.
6. Oil the new Seal and slide the cylinder Cap onto the Piston Rod starting at the bottom. **DO NOT** slide the Cylinder Cap onto the Piston Rod from the top as the upper threads will score the inside of the Cylinder Cap and damage the new Seal.
7. Replace the Piston Guide and Piston Guide Nut.

8. Replace the Cylinder Cap & Piston Rod into the Cylinder Tube. Use a paste type thread sealer, **DO NOT USE A TAPE SEALER** as this will void the Cylinders warranty.
9. Replace the Cylinder into the Driving Ram and reassemble reversing the disassembly steps.
10. Adjust the locknuts to re-center the Cylinder.

Spring Replacement

CAUTION



Springs are UNDER TENSION when fastened. Move the Main Carriage Channel down to where the top of it is slightly past the top of the beam of the Driving Ram.

NOTE: Follow the disassembly instructions for the Post Driver until the Spring Assembly is out of Driving Ram.

HD-8 and HD-10 Springs.

1. Bend the Spring Clip back to their original shape as shown below. Insert a screwdriver through the loop and twist the Spring Clip out.



2. Force the screwdriver through the first coil of the new Spring and loop the Spring Clip into the Spring. Insert the screwdriver into the Clip, twist it into the replacement Spring at least two (2) coils down. Bend the ends of the Clips back to secure the replacement.
3. Reassemble new springs by reversing these steps.
4. Once installed and Driver is reassembled, run Driving Ram up and down 10 to 15 times without impact to season your Springs. Do this **EACH** time you start a new day.

HD-12 Springs.

NOTE: On an HD-12 Post Driver Spring replacement can be done without removing the Cylinder.

1. Remove the 1/2" bolt and lock washer from bottom of both springs.
2. Then remove the 1/2" bolt and lock washer from top of both springs.
3. Remove both Springs through the bottom of the Driving Ram.
4. Reassemble new springs by reversing these steps.
5. Once installed and Driver is reassembled, run Driving Ram up and down 10 to 15 times without impact to season your Springs. Do this EACH time you start a new day.

Guide Block/Roller Replacement


NOTE: Follow the disassembly instructions for the Post Driver until the Driving Ram is removed from the Driver.

1. Remove Guide Blocks/Rollers and Shims from pins inside the Drive Ram I-Beam. **IMPORTANT: Please take care to note the number and thickness of the shims, and the location of each shim pack removed. This information is needed for correct Drive Ram reassembly.**
2. Install new Guide Blocks/Rollers with the Shims (the number and thickness noted above) at each pin location.

NOTE: Radius corners (rounded edges) on Guide Blocks/Rollers must be positioned into the channels to match the radius on the inside of the Main Carriage Channel Frame.

Post Driver Reassembly Reverse the Post Driver Disassembly instruction.


1. Lubricate the Guide Blocks with clean oil to reduce friction. Get assistance to slide Main Carriage Channel over Guide Blocks from the top of the Drive Ram.



Main Carriage Channel assembly onto Guide Blocks and Driving Ram (shown above as transparent).


2. The Main Carriage Channel should slide back and forth freely.
3. With the Drive Ram Assembly horizontal, check the up and down, and side to side movement of the Main Carriage Channel in the Drive Ram I-Beam. Movement in either direction should not be more than 1/4". **NOTE: If movement is more than 1/4" then the Guide Blocks/Rollers will need to be shimmed to reduce this play under 1/4".**
4. Install Drive Cylinder in Drive Ram Assembly from the top (upper end).
NOTE: Hydraulic Drive Ram Cylinder must be inserted in Main Carriage Channel before Springs are inserted. Position the Cylinder laying loose inside the Main Carriage Channel.
5. Install Springs from the bottom of the Post Driver between Drive Ram I-beam and Main Carriage Channel, and slide into position.
6. If removed, install two Rubber Bumpers on Road Lock Bracket. Install the Road Lock Bracket on Main Carriage Channel with bolts and nuts removed during **Post Driver Disassembly**. Leave nuts slightly loose.
7. Slide Main Carriage Channel up (forward) and install Lower Spring Bracket and Drive Cylinder Assembly onto Road Lock Bracket Bolts. Thread two new self-locking nuts onto the bolts. Install nuts just enough to fully engage threads.

8. For HD-12 attach the springs to the lower and upperspring brackets.
 - a. Install lower bolts, lock washers, and Sleeves as shown below. Thread the bolts into Lower Spring Clip just enough to fully engage the boltthreads.



HD-12 lower spring bolts, lock washers, and sleeves (arrows).


- b. Position Upper Spring Bracket ('E' below) inside the Main Carriage Channel and slide it, under Drive Cylinder, up to the Upper Spring Clips ('F' below).



HD-12 Upper Spring Bracket. Return Spring. Upper Spring Bolt. Lock washer. (Main Carriage Channel shown transparent).

- c. Install upper spring bracket bolts and lock washers through Upper Spring Bracket ('E' above). Do not tighten the bolts. Thread the bolts into return Spring Upper Clips ('F' above) just enough to fully engage the threads.

9. Attach the Drive Cylinder Piston Rod to the top of the Drive Ram I-beam using new lock washer and new self-locking nut ('D' below). Tighten the nut just enough to fully engage the threads, as shown below.
10. HD-8/HD-10 attach Springs to Upper Spring Bracket. Hook (B) retaining strap (A) to Spring Clips and Route retaining strap around top of Drive Ram Lift Yoke Bar (C), as shown below.



Upper Spring Bracket Bolts, Washers, and Nuts.


11. HD-10, install the Upper Spring Bracket on the Drive Ram Assembly.
 - a. Use the retaining strap to pull (stretch) the Springs ('B' above) just enough to align holes in Upper Spring Bracket and Drive Ram Assembly.
 - b. Install Upper Spring Bracket hardware and tighten securely.
 - c. Carefully release tension on the retaining strap and remove it from the Post Driver.
12. HD-12, attach the Upper Spring Bracket to the Drive Ram Yoke. The distance

between the mounting holes in the Upper Spring Bracket and Drive Ram Yoke will be approximately two inches.

- a. Get assistance and use a suitable round pry bar to engage one set of holes in both the bracket and drive ram yoke. Pry the bracket forward until the second sets of holes are aligned.
- b. While holding the bracket in this position, secure the bracket using hardware (bolt, washer, lock washer, and nut) in the other hole, as shown.
- c. Remove the pry bar and install remaining upper bracket hardware (bolt, washer, lock washer, and nut). Tighten both the nuts securely.
- d. Completely tighten two upper spring mount bolts.
- e. Completely tighten lower spring mount bolts that were left loose in Step 8a.
- f. Tighten drive cylinder self-locking nuts that were left loose in Step 6. Tighten each nut slightly, in turn, to align the Drive Cylinder inside the Main Carriage Channel.

13. Align the Drive Ram Cylinder.

- a. Hold the lower nut with a 1-1/8" wrench and tighten self-locking nut (D) using a 1-1/16" wrench. Then loosen the self-locking nut 1/2 turn (180 degrees), as shown below.




Drive Ram Cylinder and Self-locking Nut.

- b. Completely tighten road lock bracket nuts ('G' below were left loose in Step 6.
- c. Completely tighten self-locking nuts ('H' below) that were left loose in

Step 7. Tighten each nut slightly, in turn, to align the Drive Cylinder inside the Main Carriage Channel.

- 14. Pull Main Carriage Channel down and install Road Lock Pin ('I' below) and Lynch Pin in upper hole in Drive Ram.**



Lower Cylinder Mount, Road Lock Bracket and Lock Pin, HD-10 shown. (Main Carriage Channel shown transparent).

- 15. To avoid binding, the Drive Cylinder and Rod must be parallel to the sides of the Main Carriage Channel. If necessary, make the following adjustments:**
- a. Make sure the top Drive Ram Cylinder self-locking nut is loosened 1/2 turn.
 - b. Loosen Lower Drive Ram Cylinder self-locking nuts.
 - c. Tighten or loosen each nut slightly, in turn, to align the Drive Cylinder inside the Main Carriage Channel.

NOTE: Self-locking nuts do not have to be completely tightened against the Lower Spring Bracket.

Forward and Side Tilt Cylinder Seal Replacement

WARNING



Removing tilt cylinder(s) from the assembled Post Driver can cause an unstable condition. To avoid personal injury or death, make sure the drive ram is fully supported by other means before removing the tilt cylinders for service.

1. When removing the cylinder(s) from the assembled Post Driver, make sure the drive ram is fully supported by other means, such as a suitable overhead lifting device
2. Make sure all tilt cylinder components are clean and free of rust.
3. Lubricate the new seals with clean hydraulic fluid.
4. Install new internal O-ring seals.



Make sure the snap ring is completely seated in the cylinder tube groove.

Failure to seat the snap ring in the groove can cause the cylinder cap to be explosively ejected from the tilt cylinder tube when hydraulic pressure is applied, resulting in serious injury or even death.

Three-Point Hitch/Post Driver Assembly

1. With Road Lock Pin installed in the upper hole of Drive Ram, use a suitable overhead lifting device to raise (stand up) Main Carriage Channel Assembly.



The Main Carriage Channel Assembly is tall and heavy. To avoid tip over, resulting in serious injury or death, leave the overhead lifting device attached to the Main Carriage Channel while assembling components.



Overhead lifting device (arrow) Hydraulic Base Plate

2. For instructions on connecting the three-point hitch weldment and Post Driver Assembly after service, refer to Step 6 in the Assembly Procedure, Base Plate section of this manual.
3. Apply paste-type thread sealant to the pipe thread hose fitting. Connect drive cylinder hose to drive cylinder assembly. Tighten the hose fitting securely.

NOTE: Before using the Post Driver after service, it may be necessary to operate the hydraulic control valve levers a few times, to remove air from the hydraulic system.

Storage

For best results, always store equipment in a dry, protected location. Leaving equipment unprotected will shorten the service life of the implement.

6. Before storing, remove debris and clean the entire unit with compressed air or pressure washer.
7. Inspect the Shaver Post Driver. Replace any worn or damaged parts before using the Post Driver again.
 - Check all bolted connections. Ensure that fasteners are tight, and all pins are secured in place.
 - Inspect frame for structural fractures.
 - Make sure all warning decals are in place and legible.
 - Make sure rubber debris guard is in place and in good condition.
 - Check hydraulic cylinder(s) for signs of seal damage or excessive wear.
 - Inspect all hydraulic hoses and fittings for leaks or signs of wear.
8. After cleaning, lightly lubricate guide blocks with clean engine oil. Do not apply grease, as this will retain grit and cause excessive wear.
9. Clean and lubricate hydraulic control valve safety stop linkage. Make sure return spring and cotter pins are in good condition.
10. Apply a light coating of clean grease to all exposed hydraulic cylinder shafts to help prevent rust.
11. On HD-12-H-S Hydraulic Base Plate grease the two (2) lubrication fittings.

Troubleshooting

Troubleshooting Chart		
Problem	Possible Cause	Remedy
Drive Ram will not move or Slide freely in Main Carriage Channel.	<p>Guide Blocks/Rollers lack lubrication</p> <p>Guide Blocks/Rollers installed incorrectly.</p> <p>Incorrect clearance between Main Carriage Channel and Drive Ram I-Beam.</p> <p>Hydraulic Drive Cylinder Assembly is not parallel to Main Carriage Channel.</p> <p>Main Carriage Channel or Drive Ram is bent or damaged.</p>	<p>Lubricate with clean engine oil or spray lubricant.</p> <p>Refer to Service Information section assembly procedures for correct orientation.</p> <p>Refer to Service Information section for clearance specifications.</p> <p>Refer to Service Information section assembly Hydraulic Drive Cylinder installation and parallelism adjustment.</p> <p>Discontinue use and order replacement parts or buy new Driver.</p>
Poor performance, low or no impact, hydraulic drive cylinder will not extend.	<p>Weak or broken Drive Ram Springs.</p> <p>Broken Lower Spring Bracket.</p> <p>Bent or damaged Hydraulic Drive Cylinder Assembly.</p> <p>Main Carriage Channel is binding.</p> <p>Restricted or plugged hydraulic hoses.</p> <p>Low or no hydraulic pressure or flow from machine or power source.</p>	<p>Replace springs</p> <p>Replace Lower Spring Bracket.</p> <p>Replace or repair Hydraulic Drive Cylinder Assembly.</p> <p>Clean channels & lubricate blocks/rollers?</p> <p>Replace hydraulic hoses.</p> <p>Fill reservoir/tank with hydraulic fluid.</p>
Rubber Bumpers have premature or excessive damage.	Post Driver was not properly adjusted prior to operation and Drive Ram Guide Blocks/Rollers are contacting Rubber Bumpers.	Replace Rubber Bumpers and Adjust Post Driver.


NOTE: Refer to the Service Parts section of this manual for a illustration and description of all the parts.

NOTES

Service Parts Driver Assembly

SM-0011S-DRC - Ram Assembly, HD-8 Driver Stabilized

SM-1011S-DRC - Ram Assembly, HD-10 Driver Stabilized (SHOWN)



Driver Assembly

SM-0011S-DRC - Ram Assembly, HD-8 Driver Stabilized

SM-1011S-DRC - Ram Assembly, HD-10 Driver Stabilized (SHOWN)

Item	Qty. SM-0011S-DRC HD-8	Qty. SM-1011S-DRC HD-10 (Shown)	Part No.	Description
1	1	-	SM-0011-DRO	Ram Assembly, Driving, Only, HD-8
	-	1	SM-1011-DRO	Ram Assembly, Driving, Only, HD-10 (Shown)
2	1	-	SM-00412S	Carriage Assembly, HD-8 Stabilized
	-	1	SM-10412S	Carriage Assembly, HD-10 Stabilized (Shown)
3	1	-	SM-0011-SA	Spring Assembly, HD-8
	-	1	SM-1011-SA	Spring Assembly, HD-10 (Shown)
4	-	1	SM-1011-SBU	Bracket, Upper, HD-10 Spring
5	1	-	SM-0263-S	Cylinder Assembly, Complete HD-8
	-	1	SM-1026-S	Cylinder Assembly, Complete HD-10/12 (Shown)
6	1	-	SM-0267	Locknut, Piston, HD-8
	-	1	SM-10267	Locknut, Piston, 1-8 Nylon (Shown)
7	4*	4*	SM-00512R	Block, Nyrin
7A			SM-00510	Roller, UHMW, Driver
-	*	*	SM-00512	Nyrin Block – Pack of 4 (Not Shown)
			SM-00510-4	UHMW Rollers – Pack of 4 (Not Shown)
8	1	-	SM-0041-RLB	Bracket Assembly, Road Lock HD-8
	-	1	SM-1041-RLBPC	Plate Assembly, Road Lock HD-10 (Shown)
9	1	1	SM-1041-RLC	Clip, Road Lock
10	1	1	SM-1041-RLP	Pin, Road Lock
11	AR	AR	SM-0933	Shim, 18 Ga.(.0478") Driver (Shown)
	AR	AR	SM-0934	Shim, 14 Ga.(.0747") Driver
	AR	AR	SM-0935	Shim, 10 Ga.(.1345") Driver
12	1	-	300166	Washer, Lock 3/4"
	-	1	300112	Washer, Lock 1"(Shown)
13	2	-	300194	Bolt, Tap 3/8-16 x 2 Hex Head Gr5 Zn
	-	2	300113	Bolt, Tap 7/16-14 x 2-1/2 Hex Head Gr5 Zn (Shown)
14	2	-	300180	Hex Nut, Heavy Pattern 3/8-16 Zn
	-	2	300115	Hex Nut, Heavy Pattern 7/16-14 Zn (Shown)
15	2	-	300181	Nut, Cone 3/8-16 Lock Zn
	-	2	300356	Nut, Cone 7/16-14 Lock Zn (Shown)
16	-	2	300181	Nut, Cone 3/8-16 Lock Zn
17	-	2	300189	Bolt, Tap 3/8-16 x 1 Hex Head Gr5 Zn

*When replacing Blocks/Rollers use all of the same type.

Driver Assembly


SM-1211S-DRC - Ram Assembly, HD-12 Driver Stabilize

Item	Qty.	Part No.	Description
1	1	SM-1211-DRO	Ram Assembly, Driving, Only, HD-12
2	1	SM-12412S	Carriage Assembly, HD-12 Stabilized
3	1	SM-1211-DRSA	Spring Assembly, HD-12
4	1	SM-1211-SBU	Bracket, Upper, HD-12 Spring
5	1	SM-1026-S	Cylinder Assembly, Complete HD-10/12
6	1	SM-10267	Locknut, Piston, 1-8 Nylon
7	6	SM-00512R	Block, Nyrin
-	-	SM-00512	Nyrin Block – Pack of 4 (Not Shown)
8	1	SM-1241-RLBC	Bracket Weldment, Road Lock HD-12
9	1	SM-1041-RLC	Clip, Road Lock
10	1	SM-1041-RLP	Pin, Road Lock
11	AR	SM-0933	Shim, 18 Ga.(.0478") Driver
12	AR	SM-0934	Shim, 14 Ga.(.0747") Driver
13	AR	SM-0935	Shim, 10 Ga.(.1345") Driver
14	4	SM-0041-BR	Bumper, Rubber
15	2	SD-101-B2	Bushing, 1-7/8 OD x 5/8 ID x 2 L
16	1	300112	Washer, Lock 1" Zn
17	4	300101	Washer, Lock 1/2" Zn
18	2	300132	Screw, Cap 1/2-13 x 2 Hex Head Gr5 Zn Full Thread
19	2	300137	Bolt, Tap 1/2-13 x 4-1/2 Hex Head Gr5 Zn Full Thread
20	2	300115	Nut, Hex 7/16-14 Heavy Pattern Zn
21	2	300113	Bolt, Tap 7/16-14 x 2-1/2 Hex Head Gr5 Zn
22	2	300356	Nut, Cone 7/16-14 Lock Zn
23	2	300178	Washer , Flat 3/8" Zn
24	2	300181	Nut, Cone 3/8-16 Lock Zn
25	2	300184	Screw, Cap 3/8-16 x 1-1/2 Hex Head Gr5 Zn
26	4	300203	Nut, Hex 5/16-18 Zn
27	4	300204	Washer, Lock 5/16" Zn

Driver Assembly – Springs

SM-0011-SA - Spring Assembly, HD-8

SM-1011-SA - Spring Assembly, HD-10 (Shown)




Item	Qty. SM-0263-S HD-8	Qty. SM-1011-SA HD-10	Part No.	Description
1	1	-	SM-0011-SBL	Bracket, Lower Spring, HD-8
	-	1	SM-1011-SBL	Bracket, Lower Spring, HD-10 (Shown)
2	4	-	SM-0011-SC	Clip, Spring, HD-8
	-	4	SM-1011-SC	Clip, Spring, HD-10 (Shown)
3	2	-	SM-0011-DRSO	Spring, Driving Ram Only, HD-8
	-	2	SM-1011-DRSO	Spring, Driving Ram Only, HD-10 (Shown)
4	*	-	SM-0011-DRS	HD-8 Driving Ram Spring Complete
	-	*	SM-1011-DRS	HD-10 Driving Ram Spring Complete (Shown)

* Includes two (2) Item #2's & one (1) Item #3


Driver Assembly – HD-12 Springs

SM-1211-DRS - Spring Assembly, HD-12



Item	Qty.	Part No.	Description
1	1	SM-1211-DRSA	Spring Assembly, HD-12
2	1	SD-101-B2	Bushing, 1-7/8 OD x 5/8 ID x 2 L
3	2	300101	Washer, Lock 1/2" Zn
4	1	300132	Screw, Cap 1/2-13 x 2 Hex Head Gr5 Zn Full Thread
5	1	300137	Bolt, Tap 1/2-13 x 4-1/2 Hex Head Gr5 Zn Full Thread


SM-1211-DRSA - Spring Assembly, HD-12



Item	Qty.	Part No.	Description
1	2	SM-1211-SC	Clip, Spring, HD-12
2	1	SM-1211-DRSO	Spring, HD-12 Driving Ram Only
3	4ft. 2in.	300249	Tube, Clear Vinyl 1" ID x 1.25" OD


Driver Assembly – HD-12 Springs

SM-1211-SBU – Upper Spring Bracket, HD-12



Item	Qty.	Part No.	Description
1	1	SM-1211-SC	Clip, Spring, HD-12
2	1	300101	Washer, Lock 1/2" Zn
3	1	300132	Screw, Cap 1/2-13 x 2 Hex Head Gr5 Zn Full Thread

SM-1211-SBL – Lower Spring Bracket, HD-12




Item	Qty.	Part No.	Description
1	1	SM-1211-SC	Clip, Spring, HD-12
2	1	SD-101-B2	Bushing, 1-7/8 OD x 5/8 ID x 2 L
3	1	300101	Washer, Lock 1/2" Zn
4	1	300137	Bolt, Tap 1/2-13 x 4-1/2 Hex Head Gr5 Zn Full Thread

Driver Assembly – Road Lock Plate Assemblies & Cushions

SM-0041-RLB – Plate Assembly, Road Lock, HD-8

SM-1041-RLBPC – Plate Assembly, Road Lock, HD-10 (Shown)


SM-1241-RLB – Plate Assembly, Road Lock, HD-12



Item	Qty. SM-0041-RLB HD-8	Qty. SM-1041-RLBPC HD-10 (Shown)	Qty. SM-1241-RLB HD-12	Part No.	Description
1	1	-	-	SM-0041-RL	Plate Weldment, Road Lock, HD-8
	-	1	-	SM-1041-RLBPW	Plate Weldment, Road Lock, HD-10 (Shown)
	-	-	1	SM-1241-RLBC	Bracket Weldment, Road Lock HD-12
2	2	2	2	SM-0041-BR	Bumper, Rubber
3	2	2	2	300203	Nut, Hex 5/16-18 Zn
4	2	2	2	300204	Washer, Lock 5/16" Zn

SM-00412S – Carriage Assembly, HD-8 Stabilized


SM-10412S – Carriage Assembly, HD-10 Stabilized (Shown)



Item	Qty. SM-00412S HD-8	Qty. SM-10412S HD-10 (Shown)	Part No.	Description
1	1	-	SM-00413S	Carriage Weldment, HD-8 Main
	-	1	SM-10413S	Carriage Weldment, HD-10 Main (Shown)
2	2	2	SM-0041-BR	Bumper, Rubber
3	2	2	300203	Nut, Hex 5/16-18 Zn
4	2	2	300204	Washer, Lock 5/16" Zn

Rubber Guard Assembly


SM-1211-G – Rubber Guard Kit HD-8/10/12



Item	Qty.	Part No.	Description
1	1	SM-1211-G3	Shield, Rubber 6" x 14-3/4"
2	1	SM-0011-ST	Tag, Caution Springs
3	3	300145	Nut, Hex 1/4-20 Zn
4	3	300147	Washer, Lock 1/4 Zn
5	3	300149	Bolt, Carriage 1/4-20 x 1 Gr2 Zn

Safety Arm Assembly

SM-0011-SAA - Safety Arm Assembly




Item	Qty.	Part No.	Description
1	3	300106	Pin, Cotter 3/16 x 2-1/2
2	2	300148	Pin, Roll 1/4 x 1-1/2
3	3	300167	Nut, Lock 3/4-10 Nylon Hex Zn
4	2	300172	Bolt, Tap 3/4-10 x 2 Hex Head Gr5 Zn
5	1	MS-165	Decal, Danger Safety Arm Attachment
6	1	MS-166	Decal, Important Leave Arm Open
7	1	MS-181	Decal, Warning Pinch Point
8	1	SM-0011-SAA2	Spring, Latch
9	1	SM-0011-SAA13W	Holder Wldt., Roller
10	2	SM-0011-SAA16	Roller
11	1	SM-0011-SAAC	Frame Wldt., Safety Arm
12	1	SM-0011-SAAD	Arm Wldt., Swing Handle
13	2	SM-0011-SAAF	Washer, Flat 3/4 Double Thick
14	1	SM-015-CC	Crank, Cover

Manual Base Plate Assembly

SM-015S-DRC - Base-Plate Assembly, Complete, HD-8 (Shown)

SM-1015S-DRC - Base-Plate Assembly, Complete, HD-10



Manual Base Plate Assembly


SM-015S-DRC - Base-Plate Assembly, Complete, HD-8 (Shown)

SM-1015S-DRC - Base-Plate Assembly, Complete, HD-10

Item	Qty. SM-015S-BPC HD-8 (Shown)	Qty. SM-1015S-BPC HD-10	Part No.	Description
1	1	-	SM-015	Base-Plate Weldment,, HD-8
	-	1	SM-1015	Base-Plate Weldment,, HD-10
2	2	2	SM-015-CC	Cover, Crank, HD-8/10
3	1	1	SM-016	Crank Assembly, Side Tilt (includes SM-015-CC)
4	1	1	SM-017	Sleeve, Side Tilt Crank
5	1	1	SM-018	Nut, 3/4-10 Side Tilt Crank
6	1	1	SM-019	Crank Assembly, End Tilt (includes SM-015-CC)
7	1	1	SM-021	Nut, 1-8 End Tilt Crank
8	2	2	SM-022	Tee, End Tilt Crank
9	2	2	SM-0934	Shim, 14 Ga.(.0747") Driver
10	2	2	SM-1007	Pin, Stabilizer Base Plate HD-10
11	1	1	SM-2025-SBM	Block, Screw, Machined
12	1	1	SM-2025-SBS	Support, Screw Block
13	4	-	300101	Washer, Lock 1/2" Zn
	-	4	300216	Washer, Lock 5/8" Zn
14	4	-	300102	Nut, Hex 1/2-13 Zn
	-	4	300107	Nut, Hex 5/8-11 Zn
15	4	4	300106	Pin, Cotter 3/16 x 2-1/2 Zn
16	2	2	300111	Screw, HSSS 5/16-18 x 5/16
17	4	-	300122	Washer, Flat 1/2 Zn
	-	4	300213	Washer, Flat 5/8 Zn
18	4	-	300126	Bolt, Carriage 1/2-13 x 1-1/2 Gr5 Zn
	-	4	300221	Bolt, Carriage 5/8-11 x 2 Gr5 Zn
19	1	1	300210	Bolt, HHCS 5/16-18 x 3 Gr5 Zn
20	1	1	300254	Nut, Lock 5/16-18 Cone Hex Zn

Hydraulic Base Plate Assembly


HD-8 & HD-10 Hydraulic Base Plate



Item	Qty. HD-8	Qty. HD-10 (Shown)	Part No.	Description
-	*	-	HBP-90811	HD-8 Hydraulic Base Plate Assembly (Includes mounting hardware)
-	-	*	HBP-91011	HD-10 Hydraulic Base Plate Assembly (Includes mounting hardware) (Shown)
1	1	-	HBP-908115	Plate Weldment, Base, Hyd. HD-8
	-	1	HBP-91012	Plate Weldment, Base, Hyd. HD-10 (Shown)
2	1	1	HBP-90296	Cylinder, Hyd. Forward Tilt
-	-	-	HBP-90296-SK	Seal Kit, 2" Tilt Cylinder (Not Shown)
3	1	1	HBP-90297	Cylinder, Hyd. Side Tilt
-	-	-	HBP-90296-SK	Seal Kit, 2" Tilt Cylinder (Not Shown)
4	1	1	HBP-908-CS	Stop Assembly, Scissor
5	2	2	SM-1007	Pin, Stabilizer Base Plate HD-10
6	2	2	HBP-908133	Pin, Cyl. 13/16" Dia. x 5-1/4"
7	1	1	HBP-908134	Pin, Cyl. 1" Dia. x 2-1/2"
8	10	10	300106	Pin, Cotter 3/16 x 2-1/2 Zn
9	4	-	300126	Bolt, Carriage 1/2-13 x 1+1/2 Gr5 Zn
	-	4	300221	Bolt, Carriage 5/8-11 x 2 Gr5 Zn
10	4	-	300122	Washer, Flat 1/2 Zn
	-	4	300213	Washer, Flat 5/8 Zn
11	4	-	300102	Nut, Hex 1/2-13 Zn
	-	4	300107	Nut, Hex 5/8-11 Zn
12	4	-	300101	Washer, Lock 1/2" Zn
	-	4	300216	Washer, Lock 5/8" Zn


Hydraulic Base Plate Assembly

HD-12 Hydraulic Base Plate




Item	Qty. HD-12	Part No.	Description
-	-	HBP-912111	HD-12 Hydraulic Base Plate Assembly (Includes mounting hardware)
1	1	HBP-912115	Plate Weldment, Base, Hyd. HD-10
2	1	HBP-91217	Cylinder, Hyd. Forward Tilt
-	-	HBP-912177	Seal Kit, 2-1/2" Tilt Cylinder (Not Shown)
3	1	HBP-91218	Cylinder, Hyd. Side Tilt
-	-	HBP-912177	Seal Kit, 2-1/2" Tilt Cylinder (Not Shown)
4	1	HBP-9012-CS	Stop Assembly, Scissor
5	2	SM-1207	Pin, Stabilizer Base Plate HD-12
6	2	HBP-908133	Pin, Cyl. 13/16" Dia. x 5-1/4"
7	1	HBP-908134	Pin, Cyl. 1" Dia. x 2-1/2"
8	10	300106	Pin, Cotter 3/16 x 2-1/2 Zn
9	4	300221	Bolt, Carriage 5/8-11 x 2 Gr5 Zn
10	4	300213	Washer, Flat 5/8 Zn
11	4	300107	Nut, Hex 5/8-11 Zn
12	4	300216	Washer, Lock 5/8" Zn
13	2	300346	Fitting, Grease Straight 5/16 Drive

Manual Base Plate Valve & Hose Assembly



Item	Qty.	Part No.	Description
1	1	V-01-SP	Valve – 1 Spool
2	1	SM-002-VBP	Plate, Valve Bracket V-01, V-02
3	1	SC-50-H52	Adapter, 90° SAE #12MORB – 3/4FNPT
4	1	SC-2550-C	Adapter, 90° SAE #10MORB – 1/2NPSM
5	1	F-6902-10-12	Adapter, 45° SAE #10MORB – 3/4FNPT
6	1	SM-025-R	Hose Assembly, Hyd. 3/4 x 48"
7	1	SM-0252-R	Hose Assembly, Hyd. 3/4 x 48"
8	1	SM-0234-P	Hose Assembly, Hyd. 1/2 x 120 8MXMS 100R2
9	2	300203	Nut, Hex 5/16-18 Zn
10	2	300204	Washer, Lock 5/16 Zn
11	2	300210	Bolt, HHCS 5/16-18 x 3 Gr5 Zn


Hydraulic Base Plate Valve & Hose Assembly



Item	Qty.	Part No.	Description
1	1	V-03-SP	Valve – 3 Spool
2	1	SM-003-VBP	Plate, Valve Bracket V-03
3	1	SC-50-H52	Adapter, 90° SAE #12MORB – 3/4FNPT
4	1	SC-2550-C	Adapter, 90° SAE #10MORB – 1/2NPSM
5	1	F-6902-10-12	Adapter, 45° SAE #10MORB – 3/4FNPT
6	2	P-910181	Adapter, 90° SAE #10MORB – 1/4FNPT
7	2	F-6410-10-06	Adapter, Straight SAE #10MORB – #6FORB
8	2	F-6902R-6-4-.03	Adapter, 45° SAE #6MORB – 1/4FNPT
9	1	SM-025-R	Hose Assembly, Hyd. 3/4 x 48"
10	1	SM-0252-R	Hose Assembly, Hyd. 3/4 x 48"
11	1	SM-0234-P	Hose Assembly, Hyd. 1/2 x 120 8MXMS 100R2
12	4	SM-02111-P	Hose Assembly, Hyd. 1/4 x 26"
13	3	300203	Nut, Hex 5/16-18 Zn
14	3	300204	Washer, Lock 5/16 Zn
15	3	300210	Bolt, HHCS 5/16-18 x 3 Gr5 Zn


3-Point Hitch Assembly

MB-01-A - Bracket Assembly, CAT-I & II 3-Point Mounting w/Stands



Item	Qty	Part No.	DESCRIPTION
1	1	MB-01-AA	Bracket Wldt., 3-Point Mounting CAT-3
2	1	OS-4-22	Stand Package, Manual
3	2	MB-01A-12	Bushing (for CAT-II)
4	1	SM-1041-RLP	Pin, Road Lock (included in MB-01-AA)
5	1	300106	Pin, Cotter 3/16 x 2-1/2 (included in MB-01-AA)


MB-1201-A - Bracket Assembly, CAT-II 3-Point Mounting w/Stands (HD-10/HD-12)



Item	Qty	Part No.	DESCRIPTION
1	1	MB-1201-AA	Bracket Wldt., 3-Point Mounting CAT-2
2	1	MB-1201A-12	Pin, Top 3-Point
3	1	OS-4-22	Stand Package, Manual
4	2	300106	Pin, Cotter 3/16 x 2-1/2


3-Point Hitch Assembly

OS-4-22 - Stand Package, Manual



Item	Qty	Part No.	DESCRIPTION
1	1	OS-4-22SFBA	Bracket Wldt., Storage Stand
2	2	OS-4-22SFA	Leg Wldt., Storage Stand
3	2	300218	Screw, Cap 5/8-11 x 1-3/4 Hex Head Gr5 Zn (included in OS-4-22SFBA)
4	2	300138	Screw, Cap 1/2-13 x 4 Hex Head Gr5 Zn (included in OS-4-22SFBA)
5	2	300101	Washer, Lock 1/2 Zn (included in OS-4-22SFBA)
6	2	300102	Nut, Hex 1/2-13 Zn (included in OS-4-22SFBA)


MB-1301-A - Bracket Assembly, CAT-III 3-Point Mounting w/Stands (HD-10/HD-12)



Item	Qty	Part No.	DESCRIPTION
1	1	MB-1301-AA	Bracket Wldt., 3-Point Mounting CAT-3
2	2	OS-4-22SFA	Leg Wldt., Storage Stand
3	1	MB-1201A-12	Pin, Top 3-Point
4	2	300106	Pin, Cotter 3/16 x 2-1/2
5	2	300218	Screw, Cap 5/8-11 x 1-3/4 Hex Head Gr5 Zn (included in MB-1301-A)

Skid Steer/Loader Mounting Assembly

MBS-77-20 - Bracket Assembly, Universal Mounting




Item	Qty	Part No.	DESCRIPTION
1	1	MBS-77-20AA	Bracket Wldt., Driver Skid Loader
2	2	OS-4-22SFA	Leg Wldt., Storage Stand
3	2	300218	Washer, Lock 1/2 Zn (included in MBS-77-20AA)

Hydraulic Control Valves

Single Control Lever Valve


V-01-SP Valve – 1-Spool



Item	Qty	Part No.	DESCRIPTION
1	1	UTD-G38DARV	Valve, Main Relief , Direct Acting 1800-3000 PSI (set at 2538 PSI)
2	1	UTD-G38SCK	Spring Kit, Centering
3	1	UTD-G38SL	Handle, Safety Lever
-	1	UTD-G38SSK	Seal Kit, Spool (not shown)

Multiple Control Lever Valves


V-02-SP Valve – 2-Spool, V-03-SP Valve – 3-Spool (shown), & V-04-SP Valve – 4-Spool



Item	Qty. V-02-SP	Qty. V-03-SP	Qty. V-04-SP	Part No.	Description
1	1	1	1	UTD-G38DARV	Valve, Main Relief , Direct Acting 1800-3000 PSI (set at 2538 PSI)
2	1	2	3	UTD-G38SCK	Spring Kit, Centering
3	1	1	1	UTD-G38SL	Handle, Safety Lever
4	1	2	2	UTD-G38H	Handle, 7" Long
5	1	2	3	UTD-G38PL	Box, Handle Control
-	2	3	4	UTD-G38SSK	Seal Kit, Spool (not shown)


Self-Contained Hydraulics

OH-200 - Self-Contained Mounting Package Complete



Item	Qty	Part No.	DESCRIPTION
1	1	MBS-77-20	Bracket Assy., Universal Mtg.
2	1	OH-101	Self-Contained Mtg. Pkg. Less Brkt.


OH-101 - Self-Contained Mounting Package Less Bracket



Item	Qty.	Part No.	DESCRIPTION
1	1	OH-101-2B	Frame Weldment, Reservoir Bracket.
2	1	OH-101-1	Self-Contained Mtg. Pkg. Less Brkt.
3	2	300326	Screw, Cap 1/2 -13 x 3 Hew Head Gr5 Zn
4	2	300101	Washer, Lock 1/2 Zn
5	2	300102	Nut, Hex 1/2-13 Zn
6	4	300189	Bolt, Tap 3/8-16 x 1" Gr5 Zn
7	8	300178	Washer, Flat 3/8 Std. Zn
8	4	300181	Nut, Lock 3/8-16 Zn
9	1	300340	Bushing, Reducer 1"NPT x 3/4"NPT
10	1	SM-10252-R	Hose Assy., Hyd. 1" x 48" 1" MNPT
11	3	SM-1022-P	Hose Assy., Hyd. 1/2" x 54" 1/2" MNPT
12	1	CT-832-MC	Coupler, 1/2" Male Flat Face
13	1	CT-832-FC	Coupler, 1/2" Female Flat Face

Self-Contained Hydraulics

OH-101-1 – Pump/Motor Kit,




Item	Qty	Part No.	DESCRIPTION
1	1	700109	Adaptor, 90° SAE#16MJIC- 1" MNPT
2	1	700110	Adaptor, Straight SAE#16MORB- #8FORB
3	1	700111	Adaptor, 90° SAE#16MJIC- #20MORB
4	1	700112	Adaptor, 45° SAE#8MORB- 1/2" FNPT
5	1	CT-FC10	Valve, Check, SAE #10 Inline
6	1	OH-101-1F2	Cap, Breather
7	1	OH-101-1H	Hose Assy., Hyd. 1 x 17 SAE # 16 FJIC
8	1	OH-101-10A	Pump, Hyd. 2.69 Disp. 7/8-13T CCW
-	*	OH-101-10A-SK	Seal Kit, Pump (Not Shown)
9	1	OH-101-10B	Motor, Hyd. 3.6 Cu. In. 7/8-13T Spline
-	*	OH-101-10B-SK	Seal Kit, Motor (Not Shown)
10	1	OH-101-10F	Tank, Reservoir 8-Gal.
11	1	OH-101-10G	Mount, Adaptor Pump/Motor
12	1	OH-MP-50	Plug, Magnetic 1/2" NPT
13	2	SC-2550-C	Adaptor, 90° SAE#10MORB- 1/2" NPSM
14	1	SD-510-722	Coupling, 7/8-13T Splined 2-5/8" OD x 3"
15	1	SK-10-SMSC1A	Filter, Steel Tank 1" NPT

Driver Cylinder Assembly

SM-0263-S - Cylinder Assembly, Complete HD-8

SM-1026-S - Cylinder Assembly, Complete HD-10/12 (Shown)




Item	Qty. SM-0263-S HD-8	Qty. SM-1026-S HD-10/12	Part No.	Description
1	1	1	300111	Screw, HSS 5/16-18 x 5/16
2	1	1	SM-0269	Nut, 1/2 F. Piston Guide, HD-8/10
3	-	1	SM-0936C	Nut, Cylinder Coars Machine
	1	-	SM-018	Nut, 3/4-10 Side Tilt Crank
4	1	1	SM-02610	Guide, Piston, HD-8/10
5	-	1	SM-10261-S	Tube Wldt., Cyl. HD-10/12
	1	-	SM-0264-S	Tube Wldt., Cyl. HD-8
6	-	1	SM-10262	Cap & Seal Assy, HD-10/12
	1	-	SM-0262-D	Cap & Seal Assy, HD-8
-	-	1	SM-10265	Seal, Cup,, HD-10/12 (included in SM-10262)
	1	-	SM-0265-D	Seal, Cup,, HD-8 (included in SM-0262-D)
7	-	1	SM-10266	Rod, Piston, HD-10/12
	1	-	SM-0266	Rod, Piston, HD-8

Attachments – Pilot Augers

SM-1001-PA4 – Auger Assembly, 4” Pilot (HD-10) & SM-1001-PA6 – Auger Assembly, 6” Pilot (HD-10) (Shown)


SM-1201-PA4 – Auger Assembly, 4” Pilot (HD-12) & SM-1201-PA6 – Auger Assembly, 6” Pilot (HD-12)



Item	HD-10		HD-12		Part No.	Description
	Qty. SM-1001-PA4	Qty. SM-1001-PA6 (Shown)	Qty. SM-1201-PA4	Qty. SM-1201-PA6		
1	1	1	-	-	UTD-10PAN	Plate Assembly, Auger Mounting HD-10 (Shown)
	-	-	1	1	UTD-12PAN	Plate Assembly, Auger Mounting HD-12
2	1	1	1	1	SM-1011-PA	Motor & Hose Assembly
3	1	-	1	-	SA-304-ACC	Auger Assembly, 4" w/1" Coupler
	-	1	-	1	SA-306-ACC	Auger Assembly, 6" w/1" Coupler
4	1	1	1	1	SM-1100-PAW	Mount Weldment,
5	1	1	1	1	SK-10-SMB	Stand Weldment, Jack
6	2	2	2	2	SM-1000	Holder, Motor Mount
7	1	1	-	-	SA-001-VBP10	Bracket Weldment, Valve HD-10 (Shown)
	-	-	1	1	SA-001-VBP12	Bracket Weldment, Valve HD-12
8	1	1	1	1	GS-400	Valve, 4-Way, 3-Position Spool
9	1	1	1	1	HBP-910183	Fitting,
10	1	1	1	1	SM-023-P	Hose Assembly, Hyd. 1/2 x 35
11	4	4	4	4	300321	Bolt, Tap 3/8-16 x 1 Gr5 Zn
12	4	4	4	4	300182	Washer, Lock 3/8 Zn

Attachments – Pilot Augers

6" Auger Fish Tail & Tooth Assembly




Item	Qty.	Part No.	DESCRIPTION
1	1	SA-304-PF	Auger Point Fish Tail
2	2	SA-6230	Auger Teeth
3	2	300236	Screw, Cap 1/2-13 x 3 Hex Head Gr2 Zn
4	1	300326	Screw, Cap 1/2-13 x 2 Hex Head Gr5 Zn
5	3	300101	Washer, Lock 1/2 Zn
6	3	300102	Nut, Hex 1/2-13 Zn

NOTE: 4" Auger has non-replaceable Fish Tail Point & Teeth.

Attachments – Pilot Augers


SM-1011-PA – Motor & Hose Assembly



Item	Qty.	Part No.	DESCRIPTION
1	1	SM-1011-PAHM	Motor, Hydraulic
2	1	F-1501-08	Fitting, 90°
3	2	H-14508-120	Hose Assy., Hyd. 1/2" x 120" 1/2" MNPT
4	1	SD-510-83	Fitting, Swivel
5	2	SK-10-3P5A	Fitting, 45°
6	1	TU-13-2512D	Fitting, 90°
7	2	300101	Washer, Lock 1/2 Zn
8	2	300361	Screw, AHSS 1/2 -13 x 1-1/2 Gr5 Zn
9	1	300227	Pin, Roll 1/4 x 2-1/2

UTD-10PAN – Plate Assembly, HD-10 Motor Mount (Shown) &

UTD-12PAN – Plate Assembly, HD-12 Motor Mount




Item	Qty. UTD-10PAN (Shown)	Qty. UTD-12PAN	Part No.	DESCRIPTION
1	1	-	UTD-10PAN1	Plate Weldment, HD-10 Auger Mounting (Shown)
	-	1	UTD-12PAN1	Plate Weldment, HD-12 Auger Mounting
2	1	1	UTD-G31M	Pin, Power Head Holder
3	2	2	SM-1041-RLC	Clip, Road Lock

Attachments – Concrete Breakers

CB-1 - Concrete Breaker HD-8


CB-2 - Concrete Breaker HD-10 (Shown)

CB-3 - Concrete Breaker HD-12



Item	Qty. CB-1 HD-8	Qty. CB-2/CB-3 HD-10/HD-12	Part No.	Description
1	2	-	300102	Nut, Hex 1/2-13 Zn
	-	2	300107	Nut, Hex 5/8-11 Zn
2	2	-	300101	Washer, Lock 1/2 Zn
	-	2	300216	Washer, Lock 5/8 Zn
3	2	-	300326	Bolt, Tap 1/2-13 x 1-1/2 Hex Head Gr5 Zn
	-	2	300251	Screw, Cap 5/8-11 x 2 Hex Head Gr5 Zn


Attachments – Steel Post Holders



Item	Part No. HD-8 (Shown)	Part No. HD-10	Part No. HD-12	Description
1	SM-0011-PH	SM-1011-PH	SM-1211-PH	Steel Post Holder
2	SM-0011-PHSQ	SM-1011-PHSQ	SM-1211-PHSQ	Square Steel Post Holder


Attachments –Post Holders

SM-2-PH – Post Holder (Discontinued 2004)



Item	Qty	Part No.	DESCRIPTION
1	1	PH-2	Handle
2	2	GS-001-2	Tip, Platinol

Replacement Decals



Item	Qty. HD8	Qty. HD10/12	Part No.	Description
1	1	1	MS-162	Decal, Danger Instructions
2	1	1	MS-165	Decal, Danger Safety Arm Attachment
3	1	1	MS-163	Decal, Warning Pinch Point
4	1	1	MS-181	Decal, Warning Pinch Point
5	1	1	MS-171	Decal, Warning High Pressure Hydraulics
6	1	1	MS-105	Decal, Important Valve Instructions
7	1	1	MS-166	Decal, Important Leave Arm Open
8	1	1	SM-0011-ST	Tag, Caution Springs
9	1	1	MS-180	Decal, Cylinder Nut
10	-	1	MS-161A	Decal, Shaver Logo Large
	1	-	MS-161B	Decal, Shaver Logo Small
11	1	1	MS-280	Decal, FEMA Member Large
12	1	1	MS-USA	Decal, Made in the USA w/Flag



Shaver Manufacturing Co., LLC.
103 South Washington Avenue
P.O. Box 358 Graettinger,
IA 51342

Phone: (712) 859-3293
Fax: (712) 859-3294
sales@shavermfg.com

Limited Warranty

Shaver Manufacturing Company, LLC warrants each new Shaver product to be free from defects in material and workmanship. This warranty is applicable only for the normal service life expectancy of the product or components, not to exceed 12 consecutive months from the date of delivery of the new Shaver product to the original purchaser.

Genuine Shaver replacement parts and components will be warranted for 90 days from the date of purchase, or the remainder of the original equipment warranty period, whichever is longer.

Rubber Bumpers, Carbide Teeth, Auger Teeth and Auger Points are usable parts and not covered by warranty. Part No. SD-101-GB and SD-0301-GB Gearbox are warranted for 3 years from the date of purchase. Part No. SD-0607-GB and SD-0907-GB Gearbox are warranted for 5 years from the date of purchase. Driving Ram Springs are warranted for 60 days from the date of purchase for residential customers and 30 days from the date of purchase with a limit of 2 claims per serial numbered unit for commercial users. Tires are warranted for 90 days from the date of purchase. Replacement parts come with a 90 day warranty from date of purchase.

Under no circumstances will it cover any merchandise or components thereof, which, in the opinion of the company, have been subjected to misuse, unauthorized modification, alteration, an accident, or if a repair has been made with parts other than those obtainable through Shaver.

Our obligation under this warranty shall be limited to repairing or replacing any part that, in our judgment, shall show evidence of such defect, provided further that such part shall be returned within thirty (30) days from the date of failure to Shaver, routed through the dealer and distributor from whom the purchase was made, transportation charges prepaid. All returned items must have an RGA number. Contact Shaver at 712-859-3293 to get authorization to return, file your warranty claim and, if needed, an RGA will be provided.

This warranty shall not be interpreted to render Shaver liable for injury or damages of any kind or nature to person or property. This warranty does not extend to the loss of crops, loss because of delay in harvesting, or any expense or loss incurred for labor, substitute machinery, rental, or for any other reason.

Except as set forth above, **Shaver shall have no obligation or liability of any kind on account of any of its equipment and shall not be liable for special or consequential damages. Shaver makes no other warranty, expressed or implied, and specifically, Shaver disclaims any implied warranty of merchantability or fitness for a particular purpose. Some states or provinces do not permit limitations or exclusions of implied warranties or incidental or consequential damages, so the limitations or exclusion in this warranty may not apply.**

This warranty is subject to any existing conditions of supply which may directly affect our ability to obtain materials or manufacture replacement parts.

Shaver reserves the right to make improvements in design or changes in specifications at any time, without incurring any obligation to owners of units previously sold.

No one is authorized to alter, modify, or enlarge this warranty, nor the exclusion, limitations, and reservations.

Effective January 1, 2015

This page left intentionally blank.

Warranty Card

The Post Driver is shipped from the factory with a warranty card. If the card is lost or misplaced, please copy this page, fill in the information, and send it to Shaver Manufacturing Company.

Warranty Card

Please complete the warranty card and return to:

Shaver Manufacturing Company
103 South Washington Avenue
P.O. Box 358
Graettinger, Iowa 51342

Name _____

Address _____

City _____ State _____ Zip Code _____

Purchase / Delivery Date _____

Shaver Model Number _____

Serial Number _____

Serial Number _____

Dealer _____

This page left intentionally blank.

This page left intentionally blank.

